







# Unismart Reference Table-OEM Laserjet


"N": Non-original information

20190520

PCB code	Jig	Brand	Apex Product Code	OEM Product Code	Color	Yield	Region	For Use with
<b>K-A</b>  		HP	ARH-CB435A	CB435A	BK	1.5K	WW	HP® LaserJet P1005/P1006 Canon® LBP3018/3010/3100/3150 <i>*Life finished chips can not be reset any more</i>
			ARH-CB436A	CB436A	BK	2K	WW	HP® LaserJet P1505 HP® LaserJet M1120/M1120n/M1120a/M1120h/M1120w HP® LaserJet M1522n/M1522nf/M1522nt Canon® LBP3250 <i>*Life finished chips can not be reset any more</i>
			ARH-CC388A	CC388A	BK	1.5K	WW	HP® LaserJet P1007/P1008/P1106/P1108 HP® Laserjet pro M1136/M1213nf/M1216nfh <i>*Life finished chips can not be reset any more</i>
			ARH-CE278A	CE278A	BK	2.1K	WW	HP® LaserJet P1566/P1606/P1606dn/P1607dn/P1608dn/P1609dn/ HP® LaserJet M1530/M1536dnf Canon IC MF4410/4450/4412/4420/4550/4570/D520 <i>*Life finished chips can not be reset any more</i>
			ARH-CE285A	CE285A	BK	1.6K	WW	HP® LaserJet P1100/P1102/P1102W HP® Laserjet pro M1132/M1210/M1212nf/M1214nfh/M1217nfw/M1218nf/M1219nf Canon® LBP 6000/6018 <i>(Life finished chips can not be reset to this mldel again)</i>
			ARH-CF283A	CF283A	BK	1.5K	WW	HP® LaserJet Pro MFP M127fn/fw
			ARH-CF283X	CF283X	BK	2.2K	WW	HP® laserJet Pro /M202dw//M225dn/dw/rdn/M202n/M201dw/n
<b>K-A</b>  		HP	ARH-CB435A-N	CB435A	BK	1.5K	WW	HP® LaserJet P1005/P1006 Canon® LBP3018/3010/3100/3150 <i>(Reset the non-original data in the OEM chip)</i> <i>*Life finished chips can not be reset any more</i>
			ARH-CB436A-N	CB436A	BK	2K	WW	HP® LaserJet P1505 HP® LaserJet M1120/M1120n/M1120a/M1120h/M1120w HP® LaserJet M1522n/M1522nf/M1522nt Canon® LBP3250 <i>*Non-originalinformation</i> Life finished chips can not be reset any more
			ARH-CC388A-N	CC388A	BK	1.5K	WW	HP® LaserJet P1007/P1008/P1106/P1108 HP® Laserjet pro M1136/M1213nf/M1216nfh <i>*Non-originalinformation</i> Life finished chips can not be reset any more
			ARH-CE278A-N	CE278A	BK	2.1K	WW	HP® LaserJet P1566/P1606/P1606dn/P1607dn/P1608dn/P1609dn/ HP® LaserJet M1530/M1536dnf Canon IC MF4410/4450/4412/4420/4550/4570/D520 <i>*Non-originalinformation</i> Life finished chips can not be reset any more

ARH-CE285A-N	CE285A	BK	1.6K	WW	HP® LaserJet P1100/P1102/P1102W HP® Laserjet pro M1132/M1210/M1212nf/M1214nf/M1217nf/M1218nf/M1219nf Canon® LBP 6000/6018 *Non-original information Life finished chips can not be reset any more
ARH-CF283A-N	CF283A	BK	1.5K	WW	HP® LaserJet Pro MFP M127fn/fw
ARH-CF283X-N	CF283X	BK	2.2K	WW	HP® laserJet Pro /M202dw//M225dn/dw/rdn/M202n/M201dw/n
ARH-CB540A	CB540A	BK	2.2K	WW	HP® Color laserJet CP1215/CP1515n/CP1518ni HP® Color laserJet CM1300MFP/CM1312MFP Series/ Canon® LBP5050/8050
ARH-CB541A	CB541A	C	1.4K	WW	
ARH-CB542A	CB542A	Y	1.4K	WW	
ARH-CB543A	CB543A	M	1.4K	WW	HP® Color laserJet CP1215/CP1515n/CP1518ni HP® Color laserJet CM1300MFP/CM1312MFP Series/ Canon® LBP5050/8050 (When using the device, please use this data if the "black/color" code shown)
ARH-CB540A-L1	CB540A	BK	2.2K	WW	
ARH-CB541A-L1	CB541A	C	1.4K	WW	
ARH-CB542A-L1	CB542A	Y	1.4K	WW	
ARH-CB543A-L1	CB543A	M	1.4K	WW	
ARH-CC530A	CC530A	BK	3.5K	WW	
ARH-CC531A	CC531A	C	2.8K	WW	
ARH-CC532A	CC532A	Y	2.8K	WW	HP® Color laserJet CP2020/2025/2025n/2025dn/2025xHP® Color laserJet CM2320 MFP Series Canon® LBP-7200/7660cdn/8380cdw
ARH-CC533A	CC533A	M	2.8K	WW	
ARH-CC530A-L1	CC530A	BK	3.5K	WW	
ARH-CC531A-L1	CC531A	C	2.8K	WW	HP® Color laserJet CP2020/2025/2025n/2025dn/2025xHP® Color laserJet CM2320 MFP Series Canon® LBP- 7200/7660cdn/8380cdw (When using the device, please use this data if the "black/color" code shown)
ARH-CC532A-L1	CC532A	Y	2.8K	WW	
ARH-CC533A-L1	CC533A	M	2.8K	WW	
ARH-CE310A	CE310A	BK	1.2K	WW	
ARH-CE311A	CE311A	C	1K	WW	HP® Laserjet Pro CP1025/CP1025nw HP® LaserJet 200 color MFP M175nw/M175aCanon® LBP 7010C/7018C
ARH-CE312A	CE312A	Y	1K	WW	
ARH-CE313A	CE313A	M	1K	WW	
ARH-CE320A	CE320A	BK	2K	WW	HP® Laserjet Pro CM1415fn/CM1415fnw HP® Laserjet Pro CP1525/CP1525nw
ARH-CE321A	CE321A	C	1.3K	WW	
ARH-CE322A	CE322A	Y	1.3K	WW	
ARH-CE323A	CE323A	M	1.3K	WW	
ARH-CE410A	CE410A	BK	2.2K	WW	HP® Laserjet Enterprise 300 color M351 HP® Laserjet Enterprise 400 color M451nwHP® Laserjet Enterprise 400 color M475dn
ARH-CE410X	CE410X	BK	4K	WW	
ARH-CE411A	CE411A	C	2.6K	WW	
ARH-CE412A	CE412A	Y	2.6K	WW	
ARH-CE413A	CE413A	M	2.6K	WW	
ARH-CE410L	Increased Yield	BK	4.4K	WW	
ARH-CE411L	Increased Yield	C	3.5K	WW	
ARH-CE413L	Increased Yield	Y	3.5K	WW	
ARH-CE412L	Increased Yield	M	3.5K	WW	HPLaserJet Pro 200 color M251nw HP LaserJet Pro 200 color M276n/nw
ARH-CE410XL	Increased Yield	BK	4.7K	WW	
ARH-CE411XL	Increased Yield	C	3.7K	WW	
ARH-CE413XL	Increased Yield	Y	3.7K	WW	
ARH-CE412XL	Increased Yield	M	3.7K	WW	
ARH-CE505L	Increased Yield	BK	13.8K	WW	HP LaserJet 2050/P2053/P2054/P2055/P2056/P2057/P2053dn/P2053x/P2054dn/ P2054x P2055dn/P2055x/P2056dn/P2056x/P2057dn/P2057x


K-B



HP


ARH-CF210L	Increased Yield	BK	3.2K	WW	HPLaserJet Pro 200 color M251nw HP LaserJet Pro 200 color M276n/nw
ARH-CF211L	Increased Yield	C	2.4K	WW	
ARH-CF212L	Increased Yield	Y	2.4K	WW	
ARH-CF213L	Increased Yield	M	2.4K	WW	
ARH-CF280L	Increased Yield	BK	10.8K	WW	HP LaserJet Pro 400 M401a/d/n/dn/dw HP LaserJet Pro 400 M425dn/dw
ARH-CF380L	Increased Yield	BK	5.8K	WW	HP Color laserJet Pro M476dn MFP/M476dw MFP/M476dnw MFP
ARH-CF381L	Increased Yield	C	3.6K	WW	
ARH-CF382L	Increased Yield	Y	3.6K	WW	
ARH-CF383L	Increased Yield	M	3.6K	WW	
ARH-CE320A-L1	CE320A	BK	2K	WW	HP® Laserjet Pro CM1415fn/CM1415fnw HP® Laserjet Pro CP1525/CP1525nw (When using the device, please use this data if the "black/color" code shown)
ARH-CE321A-L1	CE321A	C	1.3K	WW	
ARH-CE322A-L1	CE322A	Y	1.3K	WW	
ARH-CE323A-L1	CE323A	M	1.3K	WW	
ARH-CE410A-L1	CE410A	BK	2.2K	WW	HP® Laserjet Enterprise 300 color M351 HP® Laserjet Enterprise 400 color M451nwHP® Laserjet Enterprise 400 color M475dn (When using the device, please use this data if the "black/color" code shown)
ARH-CE410X-L1	CE410X	BK	4K	WW	
ARH-CE411A-L1	CE411A	C	2.6K	WW	
ARH-CE412A-L1	CE412A	Y	2.6K	WW	
ARH-CE413A-L1	CE413A	M	2.6K	WW	
ARH-CE505A	CE505A	BK	2.3K	WW	HP® LaserJet P2030/P2035 HP® LaserJet 2050/P2055/P2055dn Canon® LBP-6300/6650
ARH-CE505X	CE505X	BK	6.5K	WW	HP® LaserJet 2050/P2055/P2055dn Canon® LBP-6300/6650/C-EXV 40/iR 1133
ARH-CF210A	CF210A	BK	1.6K	WW	HP® LaserJet Pro 200 color M251nw, HP® LaserJet Pro 200 color M276nw
ARH-CF210X	CF210X	BK	2.4K	WW	HP® LaserJet Pro 200 color M251nw HP® LaserJet Pro 200 color M276nw
ARH-CF211A	CF211A	C	1.8K	WW	
ARH-CF212A	CF212A	Y	1.8K	WW	
ARH-CF213A	CF213A	M	1.8K	WW	
ARH-CF210A-L1	CF210A	BK	1.6K	WW	HP® LaserJet Pro 200 color M251nw, HP® LaserJet Pro 200 color M276nw (When using the device, please use this data if the "shipping protector" code shown)
ARH-CF210X-L1	CF210X	BK	2.4K	WW	HP® LaserJet Pro 200 color M251nw HP® LaserJet Pro 200 color M276nw (When using the device, please use this data if the "shipping protector" code shown)
ARH-CF211A-L1	CF211A	C	1.8K	WW	
ARH-CF212A-L1	CF212A	Y	1.8K	WW	
ARH-CF213A-L1	CF213A	M	1.8K	WW	
ARH-CF280A	CF280A	BK	2.7K	WW	HP® LaserJet Pro 400 M401dn
ARH-CF280X	CF280X	BK	6.9K	WW	
ARH-CF350A	CF350A	BK	1.3K	WW	HP® Color LaserJet Pro MFP M176n/M177fw
ARH-CF351A	CF351A	C	1K	WW	
ARH-CF352A	CF352A	Y	1K	WW	
ARH-CF353A	CF353A	M	1K	WW	
ARH-CF380X	CF380X	BK	4.4K	WW	HP® Color laserJet Pro M476dnw MFP
ARH-CF380A	CF380A	BK	2.4K	WW	
ARH-CF381A	CF381A	C	2.7K	WW	
ARH-CF382A	CF382A	Y	2.7K	WW	
ARH-CF383A	CF383A	M	2.7K	WW	
ARH-CF380X-L1	CF380X	BK	4.4K	WW	
ARH-CF380A-L1	CF380A	BK	2.4K	WW	HP® Color laserJet Pro M476dnw MFP (When using the device, please use this data if the "shipping protector" code shown)
ARH-CF381A-L1	CF381A	C	2.7K	WW	
ARH-CF382A-L1	CF382A	Y	2.7K	WW	

K-B





HP

ARH-CF383A-L1	CF383A	M	2.7K	WW		
ARH-CB540A-N	CB540A	BK	2.2K	WW		
ARH-CB540A-L1-N	CB540A	BK	2.2K	WW		
ARH-CB541A-N	CB541A	C	1.4K	WW		
ARH-CB541A-L1-N	CB541A	C	1.4K	WW	HP® Color laserJet CP1215/CP1515n/CP1518ni HP® Color laserJet CM1300MFP/CM1312MFP Series/ Canon® LBP5050/8050 *Non-originalinformation	
ARH-CB542A-N	CB542A	Y	1.4K	WW		
ARH-CB542A-L1-N	CB542A	Y	1.4K	WW		
ARH-CB543A-N	CB543A	M	1.4K	WW		
ARH-CB543A-L1-N	CB543A	M	1.4K	WW		
ARH-CC530A-N	CC530A	BK	3.5K	WW		
ARH-CC530A-L1-N	CC530A	BK	3.5K	WW		
ARH-CC531A-N	CC531A	C	2.8K	WW		HP® Color laserJet CP2020/2025/2025n/2025dn/2025xHP® Color laserJet CM2320 MFP Series Canon® LBP-7200/7660cdn/8380cdw *Non-originalinformation
ARH-CC531A-L1-N	CC531A	C	2.8K	WW		
ARH-CC532A-N	CC532A	Y	2.8K	WW		
ARH-CC532A-L1-N	CC532A	Y	2.8K	WW		
ARH-CC533A-N	CC533A	M	2.8K	WW		
ARH-CC533A-L1-N	CC533A	M	2.8K	WW		
ARH-CE310A-N	CE310A	BK	1.2K	WW	HP® Laserjet Pro CP1025/CP1025nw HP® LaserJet 200 color MFP M175nw/M175aCanon® LBP 7010C/7018C *Non-originalinformation	
ARH-CE311A-N	CE311A	C	1K	WW		
ARH-CE312A-N	CE312A	Y	1K	WW		
ARH-CE313A-N	CE313A	M	1K	WW		
ARH-CE320A-N	CE320A	BK	2K	WW		
ARH-CE320A-L1-N	CE320A	BK	2K	WW		
ARH-CE321A-N	CE321A	C	1.3K	WW	HP® Laserjet Pro CM1415fn/CM1415fnw HP® Laserjet Pro CP1525/CP1525nw *Non-originalinformation	
ARH-CE321A-L1-N	CE321A	C	1.3K	WW		
ARH-CE322A-N	CE322A	Y	1.3K	WW		
ARH-CE322A-L1-N	CE322A	Y	1.3K	WW		
ARH-CE323A-N	CE323A	M	1.3K	WW		
ARH-CE323A-L1-N	CE323A	M	1.3K	WW		
ARH-CE410A-N	CE410A	BK	2.2K	WW		HP® Laserjet Enterprise 300 color M351 HP® Laserjet Enterprise 400 color M451nwHP® Laserjet Enterprise 400 color M475dn *Non-originalinformation
ARH-CE410A-L1-N	CE410A	BK	2.2K	WW		
ARH-CE410X-N	CE410X	BK	4K	WW		
ARH-CE410X-L1-N	CE410X	BK	4K	WW		
ARH-CE411A-N	CE411A	C	2.6K	WW	HP® Laserjet Enterprise 300 color M351 HP® Laserjet Enterprise 400 color M451nwHP® Laserjet Enterprise 400 color M475dn *Non-originalinformation	
ARH-CE411A-L1-N	CE411A	C	2.6K	WW		
ARH-CE412A-N	CE412A	Y	2.6K	WW		
ARH-CE412A-L1-N	CE412A	Y	2.6K	WW		
ARH-CE413A-N	CE413A	M	2.6K	WW		
ARH-CE413A-L1-N	CE413A	M	2.6K	WW		
ARH-CE505A-N	CE505A	BK	2.3K	WW		HP® LaserJet P2030/P2035 ; HP® LaserJet 2050/P2055/P2055dn Canon® LBP-6300/6650*Non-originalinformation
ARH-CE505X-N	CE505X	BK	6.5K	WW		HP® LaserJet 2050/P2055/P2055dn Canon® LBP-6300/6650/C-EXV 40/iR 1133 *Non-originalinformation
ARH-CF210A-N	CF210A	BK	1.6K	WW		
ARH-CF210A-L1-N	CF210A	BK	1.6K	WW		
ARH-CF210X-N	CF210X	BK	2.4K	WW		
ARH-CF210X-L1-N	CF210X	BK	2.4K	WW		



ARH-CF211A-N	CF211A	C	1.8K	WW	HP® LaserJet Pro 200 color M251nw
ARH-CF211A-L1-N	CF211A	C	1.8K	WW	HP® LaserJet Pro 200 color M276nw
ARH-CF212A-N	CF212A	Y	1.8K	WW	*Non-originalinformation
ARH-CF212A-L1-N	CF212A	Y	1.8K	WW	
ARH-CF213A-N	CF213A	M	1.8K	WW	
ARH-CF213A-L1-N	CF213A	M	1.8K	WW	
ARH-CE410L-N	Increased Yield	BK	4.4K	WW	
ARH-CE411L-N	Increased Yield	C	3.5K	WW	
ARH-CE413L-N	Increased Yield	Y	3.5K	WW	
ARH-CE412L-N	Increased Yield	M	3.5K	WW	HPLaserJet Pro 200 color M251nw
ARH-CE410XL-N	Increased Yield	BK	4.7K	WW	HP LaserJet Pro 200 color M276n/nw
ARH-CE411XL-N	Increased Yield	C	3.7K	WW	
ARH-CE413XL-N	Increased Yield	Y	3.7K	WW	
ARH-CE412XL-N	Increased Yield	M	3.7K	WW	
ARH-CE505L-N	Increased Yield	BK	13.8K	WW	HP LaserJet 2050/P2053/P2054/P2055/P2056/P2057/P2053dn/P2053x/P2054dn/ P2054x P2055dn/P2055x/P2056dn/P2056x/P2057dn/P2057x
ARH-CF210L-N	Increased Yield	BK	3.2K	WW	
ARH-CF211L-N	Increased Yield	C	2.4K	WW	HPLaserJet Pro 200 color M251nw
ARH-CF212L-N	Increased Yield	Y	2.4K	WW	HP LaserJet Pro 200 color M276n/nw
ARH-CF213L-N	Increased Yield	M	2.4K	WW	
ARH-CF280L-N	Increased Yield	BK	10.8K	WW	HP LaserJet Pro 400 M401a/d/n/dn/dw HP LaserJet Pro 400 M425dn/dw
ARH-CF380L-N	Increased Yield	BK	5.8K	WW	
ARH-CF381L-N	Increased Yield	C	3.6K	WW	HP Color laserJet Pro M476dn MFP/M476dw MFP/M476dnw MFP
ARH-CF382L-N	Increased Yield	Y	3.6K	WW	
ARH-CF383L-N	Increased Yield	M	3.6K	WW	
ARH-CF280A-N	CF280A	BK	2.7K	WW	HP® LaserJet Pro 400 M401dn
ARH-CF280X-N	CF280X	BK	6.9K	WW	*Non-originalinformation
ARH-CF350A-N	CF350A	BK	1.3K	WW	
ARH-CF351A-N	CF351A	C	1K	WW	HP® Color LaserJet Pro MFP M176n/M177fw
ARH-CF352A-N	CF352A	Y	1K	WW	
ARH-CF353A-N	CF353A	M	1K	WW	
ARH-CF380X-N	CF380X	BK	4.4K	WW	
ARH-CF380A-N	CF380A	BK	2.4K	WW	
ARH-CF381A-N	CF381A	C	2.7K	WW	HP® Color laserJet Pro M476dnw MFP
ARH-CF382A-N	CF382A	Y	2.7K	WW	
ARH-CF383A-N	CF383A	M	2.7K	WW	
ARH-CF380X-L1-N	CF380X	BK	4.4K	WW	
ARH-CF380A-L1-N	CF380A	BK	2.4K	WW	HP® Color laserJet Pro M476dnw MFP
ARH-CF381A-L1-N	CF381A	C	2.7K	WW	(When using the device, please use this data if the“shipping protector”code shown)
ARH-CF382A-L1-N	CF382A	Y	2.7K	WW	
ARH-CF383A-L1-N	CF383A	M	2.7K	WW	
ARH-CC364A	CC364A	BK	10K	WW	HP® LaserJet P4014/4014n/4015n/4015tn/4015
ARH-CC364X	CC364X	BK	24K	WW	HP® LaserJet P4515n/4515tn/4515x/p4515fn *Life finished chips can not be reset any more
ARH-CE250L	Increased Yield	BK	12K	WW	
ARH-CE251L	Increased Yield	C	7.9K	WW	HP Color laserJet
ARH-CE252L	Increased Yield	Y	7.9K	WW	CP3525/CP3525N/CP3525DN/CP3525X/CM3530/CM3530TS
ARH-CE253L	Increased Yield	M	7.9K	WW	

K-C




HP

ARH-CE400L	Increased Yield	BK	11.4K	WW	HP Laserjet Enterprise 500 color M551/N/DN/XH HP LaserJet Enterprise 500 MFP M575 dn/f
ARH-CE401L	Increased Yield	C	7.8K	WW	
ARH-CE402L	Increased Yield	Y	7.9K	WW	
ARH-CE403L	Increased Yield	M	7.10K	WW	
ARH-CE250X	CE250X	BK	10.5K	WW	HP® Color laserJet CP3525/CP3525N/CP3525DN/CP3525X/CM3530/CM3530TS
ARH-CE250A	CE250A	BK	5K	WW	
ARH-CE251A	CE251A	C	7K	WW	
ARH-CE252A	CE252A	Y	7K	WW	
ARH-CE253A	CE253A	M	7K	WW	
ARH-CE255A	CE255A	BK	6K	WW	HP® LaserJet P3015/3015D/3015N/3015X/3015dn
ARH-CE255X	CE255X	BK	12.5K	WW	
ARH-CE260X	CE260X	BK	17K	WW	HP® Color laserJet CP4525/CP4525n/CP4525dn/CP4525xh
ARH-CE260A	CE260A	BK	8.5K	WW	HP® Color laserJet CP4025/CP4025n/CP4025dn/CP4525n/CP4525dn/CP4525xh
ARH-CE261A	CE261A	C	11K	WW	
ARH-CE262A	CE262A	Y	11K	WW	
ARH-CE263A	CE263A	M	11K	WW	
ARH-CF320X	CF320X	BKXL	21K	WW	HP® Color LaserJet Enterprise MFP M680 series
ARH-CF321A	CF321A	C	16.5K	WW	
ARH-CF322A	CF322A	Y	16.5K	WW	
ARH-CF323A	CF323A	M	16.5K	WW	HP® Color LaserJetM651dn/n
ARH-CF330X	CF330X	BK	20.5k	WW	
ARH-CF320A	CF320A	BK	11.5k	WW	
ARH-CF331A	CF331A	C	15k	WW	
ARH-CF332A	CF332A	Y	15k	WW	
ARH-CF333A	CF333A	M	15k	WW	HP® Color LaserJet CM4540/4540f/4540fskm MFP
ARH-CE264X	CE264X	BK	17K	WW	
ARH-CF031A	CF031A	C	12.5K	WW	
ARH-CF032A	CF032A	Y	12.5K	WW	
ARH-CF033A	CF033A	M	12.5K	WW	HP® Color Laserjet CP5520n/dn/xh HP® Color Laserjet CP5525n/dn/xh
ARH-CE270A	CE270A	BK	13.5K	WW	
ARH-CE271A	CE271A	C	15K	WW	
ARH-CE272A	CE272A	Y	15K	WW	HP® LaserJet Enterprise 700 Color M775dn
ARH-CE273A	CE273A	M	15K	WW	
ARH-CE340A	CE340A	BK	13.5K	WW	
ARH-CE341A	CE341A	C	16K	WW	
ARH-CE342A	CE342A	Y	16K	WW	HP® LaserJet M4555MFP/M601/M602n
ARH-CE343A	CE343A	M	16K	WW	
ARH-CE390A	CE390A	BK	10K	WW	
ARH-CE390X	CE390X	BK	24K	WW	HP® LaserJet M4555MFP/M602n
ARH-CE400A	CE400A	BK	5.5K	WW	HP® Laserjet Enterprise 500 color M551/N/DN/XH
ARH-CE400X	CE400X	BK	11K	WW	
ARH-CE401A	CE401A	C	6K	WW	
ARH-CE402A	CE402A	Y	6K	WW	
ARH-CE403A	CE403A	M	6K	WW	HP® Laserjet Enterprise 500 color M551/N/DN/XH
ARH-CE740A	CE740A	BK	7K	WW	HP® Color Laserjet CP5225/CP5225n/CP5225dn
ARH-CE741A	CE741A	C	7.3K	WW	

ARH-CE742A	CE742A	Y	7.3K	WW	HP® Color LaserJet Enterprise 800 M806dn/x
ARH-CE743A	CE743A	M	7.3K	WW	
ARH-CF325X	CF325X	BK	40k	WW	HP® LaserJet Enterprise 800 M806dn/x
ARH-CF300A	CF300A	BK	29.5K	WW	
ARH-CF301A	CF301A	C	32K	WW	HP LaserJet M880z+/M880z/M880z+NFC
ARH-CF302A	CF302A	Y	32K	WW	
ARH-CF303A	CF303A	M	32K	WW	
ARH-CF310A	CF310A	BK	29K	WW	
ARH-CF311A	CF311A	C	31.5K	WW	HP® M855x+
ARH-CF312A	CF312A	Y	31.5K	WW	
ARH-CF313A	CF313A	M	31.5K	WW	
ARH-CF281A	CF281A	BK	10.5K	WW	HP LaserJet Enterprise M630
ARH-CF281X	CF281X	BK	25K	WW	
ARH-CC364A-N	CC364A	BK	10K	WW	HP® LaserJet P4014/4014n/4015n/4015tn/4015 HP® LaserJet P4515n/4515tn/4515x/p4515fn *Non-original information Life finished chips can not be reset any more
ARH-CC364X-N	CC364X	BK	24K	WW	
ARH-CE250A-N	CE250X	BK	10.5K	WW	
ARH-CE250X-N	CE250A	BK	5K	WW	HP® Color laserJet CP3525/CP3525N/CP3525DN/CP3525X/CM3530/CM3530TS *Non-original information
ARH-CE251A-N	CE251A	C	7K	WW	
ARH-CE252A-N	CE252A	Y	7K	WW	
ARH-CE253A-N	CE253A	M	7K	WW	
ARH-CE255A-N	CE255A	BK	6K	WW	HP® LaserJet P3015/3015D/3015N/3015X/3015dn *Non-original information
ARH-CE255X-N	CE255X	BK	12.5K	WW	
ARH-CE260A-N	CE260X	BK	17K	WW	HP® Color laserJet CP4525/CP4525n/CP4525dn/CP4525xh *Non-original information
ARH-CE260X-N	CE260A	BK	8.5K	WW	
ARH-CE261A-N	CE261A	C	11K	WW	HP® Color laserJet CP4025/CP4025n/CP4025dn/CP4525n/CP4525dn/CP4525xh *Non-original information
ARH-CE262A-N	CE262A	Y	11K	WW	
ARH-CE263A-N	CE263A	M	11K	WW	
ARH-CF320X-N	CF320X	BKXL	21K	WW	
ARH-CF321A-N	CF321A	C	16.5K	WW	HP® Color LaserJet Enterprise MFP M680 series
ARH-CF322A-N	CF322A	Y	16.5K	WW	
ARH-CF323A-N	CF323A	M	16.5K	WW	
ARH-CF330X-N	CF330X	BK	20.5k	WW	
ARH-CF320A-N	CF320A	BK	11.5k	WW	
ARH-CF331A-N	CF331A	C	15k	WW	HP® Color LaserJet M651 dn/n
ARH-CF332A-N	CF332A	Y	15k	WW	
ARH-CF333A-N	CF333A	M	15k	WW	
ARH-CE264X-N	CE264X	BK	17K	WW	
ARH-CE270A-N	CE270A	C	12.5K	WW	HP Color Laserjet CP5520n/dn/xh HP Color Laserjet CP5525n/dn/xh *Non-original information
ARH-CE271A-N	CE271A	Y	12.5K	WW	
ARH-CE272A-N	CE272A	M	12.5K	WW	
ARH-CE273A-N	CE273A	BK	13.5K	WW	
ARH-CE340A-N	CE340A	C	15K	WW	
ARH-CE341A-N	CE341A	Y	15K	WW	HP® Color Laserjet CP5520n/dn/xh HP® Color Laserjet CP5525n/dn/xh *Non-original information
ARH-CE342A-N	CE342A	M	15K	WW	
ARH-CE343A-N	CE343A	BK	13.5K	WW	
ARH-CE390A-N	CE390A	C	16K	WW	HP® LaserJet Enterprise 700 Color M775dn

K-C




HP



ARH-CE390X-N	CE390X	Y	16K	WW	*Non-original information
ARH-CE400A-N	CE400A	M	16K	WW	
ARH-CE400X-N	CE400X	BK	10K	WW	HP LaserJet Enterprise 500 color M551/N/DN/XH
ARH-CE401A-N	CE401A	BK	24K	WW	HP LaserJet Enterprise 500 MFP M575 dn/f





ARH-CE402A-N	CE402A	BK	5.5K	WW
ARH-CE403A-N	CE403A	BK	11K	WW
ARH-CE740A-N	CE740A	C	6K	WW
ARH-CE741A-N	CE741A	Y	6K	WW
ARH-CE742A-N	CE742A	M	6K	WW
ARH-CE743A-N	CE743A	BK	7K	WW
ARH-CF031A-N	CF031A	C	7.3K	WW
ARH-CF032A-N	CF032A	Y	7.3K	WW
ARH-CF033A-N	CF033A	M	7.3K	WW
ARH-CF325X-N	CF325X	BK	40k	WW
ARH-CF300A-N	CF300A	BK	29.5K	WW
ARH-CF301A-N	CF301A	C	32K	WW
ARH-CF302A-N	CF302A	Y	32K	WW
ARH-CF303A-N	CF303A	M	32K	WW
ARH-CF310A-N	CF310A	BK	29K	WW
ARH-CF311A-N	CF311A	C	31.5K	WW
ARH-CF312A-N	CF312A	Y	31.5K	WW
ARH-CF313A-N	CF313A	M	31.5K	WW
ARH-CF281A-N	CF281A	BK	10.5K	WW
ARH-CF281X-N	CF281X	BK	25K	WW

\*Non-original information

HP Color Laserjet CP5225/CP5225n/CP5225dn  
\*Non-original information

HP Color LaserJet CM4540/4540f/4540fskm MFP  
\*Non-original information


HP® LaserJet Enterprise 800 M806dn/x

HP LaserJet M880z+/M880z/M880z+NFC

HP® M855x+

HP LaserJet Enterprise M630

E1



Samsung

ARS-K610-5K-CHN	CLP-K660B	BK	5.5K	CHN
ARS-C610-5K-CHN	CLP-C660B	C	5K	CHN
ARS-M610-5k-CHN	CLP-M660B	M	5K	CHN
ARS-Y610-5k-CHN	CLP-Y660B	Y	5K	CHN
ARS-K610-5K-EXP	CLP-K660B	BK	5.5K	EXP
ARS-C610-5K-EXP	CLP-C660B	C	5K	EXP
ARS-M610-5K-EXP	CLP-M660B	M	5K	EXP
ARS-Y610-5K-EXP	CLP-Y660B	Y	5K	EXP
ARS-K610-5K-KOR	CLP-K660B	BK	5.5K	KOR
ARS-C610-5K-KOR	CLP-C660B	C	5K	KOR
ARS-M610-5K-KOR	CLP-M660B	M	5K	KOR
ARS-Y610-5K-KOR	CLP-Y660B	Y	5K	KOR
ARS-K610-2K-CHN	CLP-K660A	BK	2.5K	CHN
ARS-C610-2K-CHN	CLP-C660A	C	2K	CHN
ARS-M610-2K-CHN	CLP-M660A	M	2K	CHN
ARS-Y610-2K-CHN	CLP-Y660A	Y	2K	CHN
ARS-K610-2K-EXP	CLP-K660A	BK	2.5K	EXP
ARS-C610-2K-EXP	CLP-C660A	C	2K	EXP
ARS-M610-2K-EXP	CLP-M660A	M	2K	EXP
ARS-Y610-2K-EXP	CLP-Y660A	Y	2K	EXP
ARS-K610-2K-KOR	CLP-K660A	BK	2.5K	KOR
ARS-C610-2K-KOR	CLP-C660A	C	2K	KOR
ARS-M610-2K-KOR	CLP-M660A	M	2K	KOR
ARS-Y610-2K-KOR	CLP-Y660A	Y	2K	KOR
ARS-4725-3K-CHN	SCX-D4725A	BK	3K	CHN
ARS-4725-3K-EXP	SCX-D4725A	BK	3K	EXP
ARS-4725-3K-KOR	SCX-D4725A	BK	3K	KOR

Samsung® CLP-610/660  
Samsung® CLX-6200

Samsung®SCX-4725

Xerox

ARX-730-3K	113R00730	BK	3K	WW
------------	-----------	----	----	----

Xerox®Phaser 3200MFP

Due to the chip features, Unismart can just reset according to the OEM chip's original model/color/yield/region, please select the right model/color/yield/region in Unismart to match the OEM chip's, or else the chip may be locked to dead "

## E2



Due to the chip features, Unismart can just reset according to the OEM chip's original model/color/yield/region, please select the right model/color/yield/region in Unismart to match the OEM chip's, or else the chip may be locked to dead "







Samsung	ARS-3050-4K-CHN	ML-D3050A	BK	4K	CHN	Samsung@ML-3050/3051N/3051ND
	ARS-3050-4K-KOR	ML-D3050A	BK	4K	KOR	
	ARS-3050-4K-EXP	ML-D3050A	BK	4K	EXP	
	ARS-3050-8K-CHN	ML-D3050B	BK	8K	CHN	
	ARS-3050-8K-KOR	ML-D3050B	BK	8K	KOR	
	ARS-3050-8K-EXP	ML-D3050B	BK	8K	EXP	
	ARS-3470-4K	ML-D3470A	BK	4K	WW	Samsung@ML-3470D/3471ND
	ARS-3470-10K	ML-D3470B	BK	10K	WW	
	ARS-206S-EXP	MLT-D206S	BK	4K	EXP	Samsung@ SCX-5935FN
	ARS-206L-EXP	MLT-D206L	BK	10K		
	ARS-208S-4K-KOR	MLT-D208S	BK	4K	KOR	Samsung@ SCX-5635FNK Samsung@ ML-3475D/ND;ML-3475D/GOV;ML-3475ND/GOV
	ARS-208L-KOR	MLT-D208L	BK	10K		
	ARS-208S-4K-CHN	MLT-D208S/XIL	BK	4K	CHN	Samsung@ SCX-5635FN/5635HN
	ARS-208L-CHN	MLT-D208L/XIL	BK	10K		
	ARS-208S-4K-EXP	MLT-D208S	BK	4K	EXP	Samsung@ SCX-5635FN/5835FN
	ARS-208L-EXP	MLT-D208L	BK	10K		
	ARS-5530-4K-CHN	SCX-D5530A	BK	4K	CHN	Samsung@ SCX-5330N/5530/5530FN /5525
	ARS-5530-4K-KOR	SCX-D5530A	BK	4K	KOR	
	ARS-5530-4K-EXP	SCX-D5530A	BK	4K	EXP	
	ARS-5530-8K-CHN	SCX-D5530B	BK	8K	CHN	
ARS-5530-8K-KOR	SCX-D5530B	BK	8K	KOR		
ARS-5530-8K-EXP	SCX-D5530B	BK	8K	EXP		
Xerox	ARX-1245-4K	106R01245	BK	4K	WW	Xerox@Phaser 3428D/3428DN
	ARX-1246-8K	106R01246	BK	8K	WW	Xerox@Phaser 3300
	ARX-1411-4K	106R01411	BK	4K	WW	
	ARX-1412-8K	106R01412	BK	8K	WW	Xerox@3435MFP
	ARX-1414-4K	106R01414	BK	4K	WW	
ARX-1415-10K	106R01415	BK	10K	WW		
Dell	ARD-2208-3K	330-2208	BK	3K	WW	Dell@ 2335/2335N/2355
	ARD-2209-6K	330-2209	BK	6K	WW	
	ARD-0611-10K	330-0611	BK	10K	WW	Dell@ 2355
	ARD-1815-3K	310-7943	BK	3K	WW	Dell@ 1815/1815N
ARD-1815-5K	310-7945	BK	5K	WW		
Ricoh	ARR-3200-8K	402888	BK	8K	WW	Ricoh@ SP3200
	ARR-3300-5K	406212	BK	5K	WW	Ricoh@ SP3300

## E3

Due to the chip features, Unismart can just reset according to the OEM chip's original model/color/yield/region, please select the right model/color/yield/region in Unismart to match the OEM chip's, or else the chip may be locked to dead "




Samsung	ARS-2850-2K-CHN	ML-D2850A	BK	2K	CHN	Samsung@2850/2850N/2850DN
	ARS-2850-2K-EXP	ML-D2850A	BK	2K	EXP	
	ARS-2850-2K-KOR	ML-D2850A	BK	2K	KOR	
	ARS-2850-5K-CHN	ML-D2850B	BK	5K	CHN	
	ARS-2850-5K-EXP	ML-D2850B	BK	5K	EXP	
	ARS-2850-5K-KOR	ML-D2850B	BK	5K	KOR	
Xerox	ARX-1373-3K5	106R01373	BK	3.5K	WW	Xerox@3250/3250d/3250dn
	ARX-1374-5K	106R01374	BK	5K	WW	

<b>F</b> Due to the chip features, Unismart can just reset according to the OEM chip's original model/color/yield/region, please select the right model/color/yield/region in Unismart to match the OEM chip's, or else the chip may be locked to dead "		<b>Samsung</b>	ARS-1630-2K-CHN	ML-D1630A	BK	2K	CHN	Samsung®ML-1630			
			ARS-1630-2K-KOR	ML-D1630A	BK	2K	KOR				
			ARS-1630-2K-EXP	ML-D1630A	BK	2K	EXP				
						ARS-4500-2K-CHN	SCX-4500A	BK	2K	CHN	Samsung®SCX-4500
						ARS-4500-2K-KOR	SCX-4500A	BK	2K	KOR	
						ARS-4500-2K-EXP	SCX-4500A	BK	2K	EXP	
<b>F2</b> Due to the chip features, Unismart can just reset according to the OEM chip's original model/color/yield/region, please select the right model/color/yield/region in Unismart to match the OEM chip's, or else the chip may be locked to dead "		<b>Samsung</b>				ARS-4550-10-CHN	ML-D4550A	BK	10K	CHN	Samsung®ML-4550(OEM size)
						ARS-4550-10-KOR	ML-D4550A	BK	10K	KOR	
						ARS-4550-10-EXP	ML-D4550A	BK	10K	EXP	
			ARS-4550-20-CHN	ML-D4550B	BK	20K	CHN				
			ARS-4550-20-KOR	ML-D4550B	BK	20K	KOR				
			ARS-4550-20-EXP	ML-D4550B	BK	20K	EXP				
			ARS-308S-KOR	MLT-D308S	BK	10K	KOR	Samsung® ML-4555			
			ARS-308L-KOR	MLT-D308L	BK	20K	KOR				
<b>F3</b> Due to the chip features, Unismart can just reset according to the OEM chip's original model/color/yield/region, please select the right model/color/yield/region in Unismart to match the OEM chip's, or else the chip may be locked to dead "		<b>Samsung</b>	ARS-560R-3K-CHN	SF-D560RA	BK	3K	CHN	Samsung® SF-560R/560RC/565RN Samsung® ML-5100			
			ARS-560R-3K-KOR	SF-D560RA	BK	3K	KOR				
			ARS-560R-3K-EXP	SF-D560RA	BK	3K	EXP				
<b>G</b> Due to the chip features, Unismart can just reset according to the OEM chip's original model/color/yield/region, please select the right model/color/yield/region in Unismart to match the OEM chip's, or else the chip may be locked to dead "		<b>Samsung</b>	ARS-K350-4K-CHN	CLP-K350A	BK	4K	CHN	Samsung® CLP-350/350N			
			ARS-C350-2K-CHN	CLP-C350A	C	2K	CHN				
			ARS-M350-2K-CHN	CLP-M350A	M	2K	CHN				
			ARS-Y350-2K-CHN	CLP-Y350A	Y	2K	CHN				
			ARS-K350-4K-EXP	CLP-K350A	BK	4K	EXP				
			ARS-C350-2K-EXP	CLP-C350A	C	2K	EXP				
			ARS-M350-2K-EXP	CLP-M350A	M	2K	EXP				
			ARS-Y350-2K-EXP	CLP-Y350A	Y	2K	EXP				
			ARS-K350-4K-KOR	CLP-K350A	BK	4K	KOR				
			ARS-C350-2K-KOR	CLP-C350A	C	2K	KOR				
			ARS-M350-2K-KOR	CLP-M350A	M	2K	KOR				
ARS-Y350-2K-KOR	CLP-Y350A	Y	2K	KOR							
<b>RST-SINDOH</b> 		<b>SindoRico</b> h	S400T2HK	S400T2HK	BK	2.5K	KOR	SindoRico® A400/A400x/A401/A401dn/A402dn/A405/A405t/A406/A406dn/A407dn/A405/A405t/A406/A406dn/A407dn			
			S400T5K	S400T5K	BK	5K	KOR	SindoRico® A400/A400x/A401/A401dn/A402dn/A405/A405t/A406/A406dn/A407dn/A405/A405t/A406/A406dn/A407dn			

\*There are two kinds of OEM chips; Unismart can only reset the one shown on photo.

11

### RST-1640




\*Resetting 100% toner level costs Unismart credits. Resetting lower than 100% toner level is possible and the chip after such reset is workable; in this case, Unismart credits will not be taken; Unismart will show you the presentage of toner level reset.



Samsung

S400T8K	S400T8K	BK	8K	KOR	SindoRicoH® A400x/A401/A401dn/A402dn/A405/A405t/A406/A406dn/A407dn/A405/A405t/A406/A406dn/A407dn
D106-2.0KEXP	MLT-D106S	BK	2K	EXP	Samsung®ML-2245
D108-1.5KDOM	MLT-D108S	BK	1.5K	DOM	Samsung®ML-1640/2240 Samsung®ML-1641/2241
D108-1.5KEXP	MLT-D108S	BK	1.5K	EXP	
D108-1.5KCHN	MLT-D108S	BK	1.5K	CHN	
D108-1.5KEUR	MLT-D1082S	BK	1.5K	EUR	

### RST-1640




\*Resetting 100% toner level costs Unismart credits. Resetting lower than 100% toner level is possible and the chip after such reset is workable; in this case, Unismart credits will not be taken; Unismart will show you the presentage of toner level reset.



Samsung

D105-1.5KDOM	MLT-D105S	BK	1.5K	DOM	Samsung®ML-1916K/1915K/1910K/2525K/2580NK Samsung®SCX-4610K/4605K/1600K/4623K/4623FK/4623FN
D105-1.5KEXP	MLT-D105S	BK	1.5K	EXP	
D105-2.5KDOM	MLT-D105L	BK	2.5K	DOM	Samsung®CF-650/650F ; Samsung®ML-2525/2525W/2540,SCX-4600/4623F,SF-650/650P
D105-2.5KEXP	MLT-D105L	BK	2.5K	EXP	
D105-1.5KEUR	MLT-D1052S	BK	1.5K	EUR	Samsung®ML-1910/1915/2525/2525W/2580N Samsung®SCX-4600/4623F/4623FN Samsung®SF-651/651P
D105-2.5KEUR	MLT-D1052L	BK	2.5K	EUR	
D105-1.5KCHN	MLT-D1053S/XIL	BK	1.5K	CHN	Samsung®ML-1911/2526/2581N Samsung ® SCX-4600/4623FN Samsung ® SF-651/651P
D105-2.5KCHN	MLT-D1053L/XIL	BK	2.5K	CHN	
D209-2.0KDOM	MLT-D209S	BK	2K	DOM	Samsung®ML-2855ND;ML-2855NDK/G,ML-2853D/ND Samsung® ML-2853D/GOV,ML-2853ND/GOV Samsung®SCX-4824FN/4828FN;SCX-4824HN/4828HN
D209-2.0KEXP	MLT-D209S	BK	2K	EXP	
D209-2.0KCHN	MLT-D209S	BK	2K	CHN	
D209-5.0KDOM	MLT-D209L	BK	5K	DOM	
D209-5.0KEXP	MLT-D209L	BK	5K	EXP	
D209-5.0KCHN	MLT-D209L	BK	5K	CHN	
D209-2.0KEUR	MLT-D2092S	BK	2K	EUR	Samsung®SCX-4824FN/4828FN
D209-5.0KEUR	MLT-D2092L	BK	5K	EUR	
K508-2.5KCHN	CLT-K508S	BK	2.5K	CHN	Samsung®CLP-620ND
C508-2.0KCHN	CLT-C508S	C	2K	CHN	
M508-2.0KCHN	CLT-M508S	M	2K	CHN	
Y508-2.0KCHN	CLT-Y508S	Y	2K	CHN	
K508-5.0KCHN	CLT-K508L	BK	5K	CHN	
C508-4.0KCHN	CLT-C508L	C	4K	CHN	
M508-4.0KCHN	CLT-M508L	M	4K	CHN	
Y508-4.0KCHN	CLT-Y508L	Y	4K	CHN	

### RST-1640



K508-2.5KEXP	CLT-K508S	BK	2.5K	EXP	Samsung®CLP-620ND/670ND
C508-2.0KEXP	CLT-C508S	C	2K	EXP	
M508-2.0KEXP	CLT-M508S	M	2K	EXP	
Y508-2.0KEXP	CLT-Y508S	Y	2K	EXP	


\*Reseting 100% toner level costs Unismart credits.  
 Resetting lower than 100% toner level is possible and the chip after such reset is workable; in this case, Unismart credits will not be taken; Unismart will show you the presentage of toner level reset.



**Samsung**

K508-5.0KEXP	CLT-K508L	BK	5K	EXP	Samsung@CLX-6220FX/6250FX
C508-4.0KEXP	CLT-C508L	C	4K	EXP	
M508-4.0KEXP	CLT-M508L	M	4K	EXP	
Y508-4.0KEXP	CLT-Y508L	Y	4K	EXP	
K508-2.5KEUR	CLT-K508S	BK	2.5K	EUR	Samsung@CLP-620ND/670ND
C508-2.0KEUR	CLT-C508S	C	2K	EUR	Samsung@CLX-6220FX/6250FX

# RST-1640



\*Resetting 100% toner level costs Unismart credits. Resetting lower than 100% toner level is possible and the chip after such reset is workable; in this case, Unismart credits will not be taken; Unismart will show you the presentage of toner level reset.

Samsung

M508-2.0KEUR	CLT-M508S	M	2K	EUR
Y508-2.0KEUR	CLT-Y508S	Y	2K	EUR
K508-5.0KEUR	CLT-K508L	BK	5K	EUR
C508-4.0KEUR	CLT-C508L	C	4K	EUR
M508-4.0KEUR	CLT-M508L	M	4K	EUR
Y508-4.0KEUR	CLT-Y508L	Y	4K	EUR
K508-2.5KDOM	CLT-K508S	BK	2.5K	DOM
C508-2.0KDOM	CLT-C508S	C	2K	DOM
M508-2.0KDOM	CLT-M508S	M	2K	DOM
Y508-2.0KDOM	CLT-Y508S	Y	2K	DOM
K508-5.0KDOM	CLT-K508L	BK	5K	DOM
C508-4.0KDOM	CLT-C508L	C	4K	DOM
M508-4.0KDOM	CLT-M508L	M	4K	DOM
Y508-4.0KDOM	CLT-Y508L	Y	4K	DOM
K609-7.0KDOM	CLT-K609S	BK	7K	DOM
C609-7.0KDOM	CLT-C609S	C	7K	DOM
M609-7.0KDOM	CLT-M609S	M	7K	DOM
Y609-7.0KDOM	CLT-Y609S	Y	7K	DOM
K609-7.0KEUR	CLT-K6092S	BK	7K	EUR
C609-7.0KEUR	CLT-C6092S	C	7K	EUR
M609-7.0KEUR	CLT-M6092S	M	7K	EUR
Y609-7.0KEUR	CLT-Y6092S	Y	7K	EUR
K609-7.0KEXP	CLT-K609S	BK	7K	EXP
C609-7.0KEXP	CLT-C609S	C	7K	EXP
M609-7.0KEXP	CLT-M609S	M	7K	EXP
Y609-7.0KEXP	CLT-Y609S	Y	7K	EXP

Samsung@CLP-620ND/670ND  
Samsung@CLX-6220FX/6250FX


Samsung@CLP-620ND/670ND

Samsung@ CLP-770ND

Samsung@CLP-770ND/775ND

Samsung@ CLP-775ND

# RST-1640



\*Resetting 100% toner level costs Unismart credits. Resetting lower than 100% toner level is possible and the chip after such reset is workable; in this case, Unismart credits will not be taken; Unismart will show you the presentage of toner level reset.

Xerox

1499-2.0KCHN	106R01499	BK	2K	CHN
1500-5.0KCHN	106R01500	BK	5K	CHN
775-2.0KAP	CWAA0775	BK	2K	AP
776-5.0KAP	CWAA0776	BK	5K	AP
1485-2.0KEXP/EUR	106R01485	BK	2K	EXP/EUR
1486-4.1KEXP/EUR	106R01486	BK	4.1K	EXP/EUR
984-2.5KCHN	108R00984	BK	2.5K	CHN
983-1.5KCHN	_____	BK	1.5K	CHN
805-2.5KAP	CWAA0805	BK	2.5K	AP
804-1.5KAP	_____	BK	1.5K	AP
908-1.5KEXP	108R00908	BK	1.5K	EXP
909-2.5KEXP	108R00909	BK	2.5K	EXP

XEROX@Workcenter 3210/3220

XEROX@Workcenter 3140/3155/3160

Dell


1130-1.5KUS		BK	1.5K	US
1130-2.5KUS		BK	2.5K	US

Dell@1130/1130N/1133/1135N \*EXP/EUR Universal

# RST-1640

K409-1.5KDOM	CLT-K409S	BK	1.5K	DOM
C409-1.0KDOM	CLT-C409S	C	1K	DOM
M409-1.0KDOM	CLT-M409S	M	1K	DOM
Y409-1.0KDOM	CLT-Y409S	Y	1K	DOM
K409-1.5KEXP	CLT-K409S	BK	1.5K	EXP

Samsung@CLP-310/315/310N/315W  
Samsung@CLX-3170FN/3175N/3175/3175FN/3175FW



\*Resetting 100% toner level costs Unismart credits. Resetting lower than 100% toner level is possible and the chip after such reset is workable; in this case, Unismart credits will not be taken; Unismart will show you the presentage of toner level reset.



Samsung

C409-1.0KEXP	CLT-C409S	C	1K	EXP
M409-1.0KEXP	CLT-M409S	M	1K	EXP
Y409-1.0KEXP	CLT-Y409S	Y	1K	EXP
K409-1.5KCHN	CLT-K409S/XIL	BK	1.5K	CHN
C409-1.0KCHN	CLT-C409S/XIL	C	1K	CHN
M409-1.0KCHN	CLT-M409S/XIL	M	1K	CHN
Y409-1.0KCHN	CLT-Y409S/XIL	Y	1K	CHN
K409-1.5KEUR	CLT-K4092S	BK	1.5K	EUR
C409-1.0KEUR	CLT-C4092S	C	1K	EUR
M409-1.0KEUR	CLT-M4092S	M	1K	EUR
Y409-1.0KEUR	CLT-Y4092S	Y	1K	EUR

Samsung@CLP-310/315/310N/315W  
Samsung@CLX-3170FN/3175N/3175/3175FN/3175FW

Samsung@CLP-315/310N

Samsung@ CLP-315W/310  
Samsung@ CLX-3175/3175N/3175FN/3175FW/3170

Dell

1230K-1.5K		BK	1.5K	WW
1230C-1K		C	1K	WW
1230M-1K		M	1K	WW
1230Y-1K		Y	1K	WW

Dell@ 1230C/1235CN

## RST-1640



\*Resetting 100% toner level costs Unismart credits. Resetting lower than 100% toner level is possible and the chip after such reset is workable; in this case, Unismart credits will not be taken; Unismart will show you the presentage of toner level reset.



Samsung

D109-2.0KEXP	MLT-D109S	BK	2K	EXP
D109-2.0KCHN	MLT-D109S	BK	2K	CHN
D109-2.0KEUR	MLT-D1092S	BK	2K	EUR
D109-2.0KDOM		BK	2K	DOM

Samsung@SCX-4300/4310/4315

Samsung@SCX-4300K/4310K/4315K

## RST-1640



\*Resetting 100% toner level costs Unismart credits. Resetting lower than 100% toner level is possible and the chip after such reset is workable; in this case, Unismart credits will not be taken; Unismart will show you the presentage of toner level reset.



(standard)

Samsung

D104-1.5KEXP	MLT-D104S	BK	1.5K	EXP
D104-1.5KDOM	MLT-D104S	BK	1.5K	DOM
D104-1.5KEUR	MLT-D1042S	BK	1.5K	EUR

Samsung@ ML-1660/1665/1667/1670/1671/1675/1676/1677/1678/1685/1867  
Samsung@ ML-1665K/1660K/1865W  
Samsung@ SCX-3200

Samsung@ML-1665/DCS/1665K/1661K/1660K/1678/1861/1865

Samsung@ML-1660/1665/1860/1865/1670 Samsung@ SCX-3205W

## RST-1640



Samsung

K407-1.5KEXP	CLT-K407S	BK	1.5K	EXP
C407-1.0KEXP	CLT-C407S	C	1K	EXP
M407-1.0KEXP	CLT-M407S	M	1K	EXP
Y407-1.0KEXP	CLT-Y407S	Y	1K	EXP
K407-1.5KDOM	CLT-K407S	BK	1.5K	DOM
C407-1.0KDOM	CLT-C407S	C	1K	DOM
M407-1.0KDOM	CLT-M407S	M	1K	DOM

Samsung@CLP-325/320,CLX-3285/3185

Samsung@CLP-325/320,CLX-3285

\*Resetting 100% toner level costs Unismart credits.

Resetting lower than 100% toner level is possible and the chip after such reset is workable; in this case, Unismart credits will not be taken; Unismart will show you the presentage of toner level reset.



Y407-1.0KDOM	CLT-Y407S	Y	1K	DOM
K407-1.5KEUR	CLT-K407S	BK	1.5K	EUR
C407-1.0KEUR	CLT-C407S	C	1K	EUR
M407-1.0KEUR	CLT-M407S	M	1K	EUR
Y407-1.0KEUR	CLT-Y407S	Y	1K	EUR

Samsung@CLP-325/320,CLX-3185

## RST-1640



\*Resetting 100% toner level costs Unismart credits. Resetting lower than 100% toner level is possible and the chip after such reset is workable; in this case, Unismart credits will not be taken; Unismart will show you the presentage of toner level reset.



Samsung

K407-1.5KCHN	CLT-K407S	BK	1.5K	CHN
C407-1.0KCHN	CLT-C407S	C	1K	CHN
M407-1.0KCHN	CLT-M407S	M	1K	CHN
Y407-1.0KCHN	CLT-Y407S	Y	1K	CHN

Samsung@CLP-326/321,CLX-3186

## RST-1640



\*Resetting 100% toner level costs Unismart credits. Resetting lower than 100% toner level is possible and the chip after such reset is workable; in this case, Unismart credits will not be taken; Unismart will show you the presentage of toner level reset.



Samsung

D205-2.0KCHN	MLT-D205S	BK	2K	CHN
D205-5.0KCHN	MLT-D205L	BK	5K	CHN
D205-10KCHN	MLT-D205E	BK	10K	CHN
D205-2.0KEXP	MLT-D205S	BK	2K	EXP
D205-5.0KEXP	MLT-D205L	BK	5K	EXP
D205-10KEXP	MLT-D205E	BK	10K	EXP
D205-2.0KEUR	MLT-D205S	BK	2K	EUR
D205-5.0KEUR	MLT-D205L	BK	5K	EUR
D205-10KEUR	MLT-D205E	BK	10K	EUR
D205-2.0KDOM	MLT-D205S	BK	2K	DOM
D205-5.0KDOM	MLT-D205L	BK	5K	DOM
D205-10KDOM	MLT-D205E	BK	10K	DOM
D305-7.0KDOM	MLT-D305S	BK	7K	DOM
D305-15KDOM	MLT-D305L	BK	15K	DOM
D305-7.0KEXP	MLT-D305S	BK	7K	EXP
D305-15KEXP	MLT-D305L	BK	15K	EXP
D305-7.0KEUR	MLT-D305S	BK	7K	EUR
D305-15KEUR	MLT-D305L	BK	15K	EUR

Samsung@ML-3310D/3310ND/3710D/3710ND

Samsung@SCX-5637HR/4833HD

Samsung@ML-3710ND SCX-5637HR

Samsung@ ML-3310ND/3312ND/3710ND/3310D/3710D/3710DW/3712ND/3712DW  
Samsung@ SCX-4833HD/4833FD/4833FR/4835FR/5637HR/5637FR/5639FR/5737FW/5739FW

Samsung@ ML-3710ND/3710D/3710DW/3712ND/3712DW  
Samsung@ SCX-5637HR/5637FR/5639FR/5737FW/5739FW

Samsung@ ML-3310ND/3710ND/3310D/3710D/3710DW  
Samsung@ SCX-4833HD/4833FD/4833FR/4835FR/5737FW

Samsung@ ML-3710ND/3710D/3710DW/  
Samsung@ SCX-5737FW

Samsung@ML-3300/3310D/3310ND/3710D/3710ND  
Samsung@ SCX-5637FR/4833FR/4833FD

Samsung@ML-3710D/3710ND SCX-5637FR

Samsung@ ML-3753ND

Samsung@ ML-3750ND

Samsung@ ML-3750ND

Xerox

2305-5.0KEXP	106R02305	BK	5K	EXP
2307-11KEXP	106R02307	BK	11K	EXP
2309-2.3KEXP	106R02309	BK	2.3K	EXP
2310-5.0KME	106R02310	BK	5K	ME
2311-5.0KEXP	106R02311	BK	5K	EXP


Xerox@ Phaser 3320

Xerox@ Workcenter 3315 Xerox@ Workcenter 3325

Xerox@ Workcenter 3315 Xerox@ Workcenter 3325



## RST-1640




\*Resetting 100% toner level costs Unismart credits. Resetting lower than 100% toner level is possible and the chip after such reset is workable; in this case, Unismart credits will not be taken; Unismart will show you the presentage of toner level reset.



Samsung

2313-11KEXP	106R02313	BK	11K	EXP	Xerox® Workcenter 3325
D307-7.0KDOM	MLT-D307S	BK	7K	DOM	Samsung® ML-4510ND/4512ND
D307-15KDOM	MLT-D307L	BK	15K	DOM	
D307-20KDOM	MLT-D307E	BK	20K	DOM	
D307-7.0KEUR	MLT-D307S	BK	7K	EUR	Samsung® ML-4510/4512
D307-15KEUR	MLT-D307L	BK	15K	EUR	
D307-20KEUR	MLT-D307E	BK	20K	EUR	

## RST-1640



\*Resetting 100% toner level costs Unismart credits. Resetting lower than 100% toner level is possible and the chip after such reset is workable; in this case, Unismart credits will not be taken; Unismart will show you the presentage of toner level reset.



Samsung

D307-7.0KEXP	MLT-D307S	BK	7K	EXP	Samsung®ML-4510ND/ML-5010ND/5015ND
D307-15KEXP	MLT-D307L	BK	15K	EXP	
D307-20KEXP	MLT-D307E	BK	20K	EXP	
D307-7.0KCHN	MLT-D307S	BK	7K	CHN	Samsung® ML-4510ND
D307-15KCHN	MLT-D307L	BK	15K	CHN	
D307-20KCHN	MLT-D307E	BK	20K	CHN	



## RST-RICOH-5200

MPC3300-BK-AU	841128	BK	20K	AU	Ricoh MPC3300
MPC3501-BK-AU	841436	BK	22K	AU	Ricoh MPC3501
MPC3501-Y-AU	841437	Y	15K		
MPC3501-M-AU	841438	M	15K		
MPC3501-C-AU	841439	C	15K		
MPC5501-BK-NA	841582	BK	25.5K	NA	Ricoh MPC5501
MPC5501-Y-NA	841453	Y	17K		
MPC5501-M-NA	841454	M	17K		
MPC5501-C-NA	841455	C	17K		
MPC5000-BK-NA	841284	BK	23K	NA	Ricoh MPC5000
MPC5001-BK-JP	600164	BK	10.4K	JP	Ricoh MPC5001
MPC5001-Y-JP	600165	Y	7.6K		
MPC5001-M-JP	600166	M	7.6K		
MPC5001-C-JP	600167	C	7.6K		
SP5200-BK-NA	406683	BK	25K	NA	Ricoh GSA SP5200DNG/GSA SP 5200SG/GSA SP 5200DN/SP 5200S/SP 5200SHT/SP 5200SHW
SP430-BK-CHN	821233	BK	21K	CHN	Ricoh SPC430DN
SP430-Y-CHN	821234	Y	24K		
SP430-M-CHN	821235	M	24K		



Ricoh

SP430-C-CHN	821236	C	24K		
SP435-BK-NA	821243	BK	11K	NA	Ricoh SPC435DN
SP435-Y-NA	821244	Y	13K		
SP435-M-NA	821245	M	13K		
SP435-C-NA	821246	C	13K		
MPC3000-K	810407	K	20K		
MPC3000-C	823418	C	15K		
MPC3000-M	836429	M	15K		
MPC3000-Y	849430	Y	15K		
MPC3000-M-EUR	884948	M	15K	EUR	Ricoh MPC3000
MPC3000-M-EUR	884956	M	15K		
MPC3000-K-AU	888640	K	20K	AU	Ricoh MPC3000
MPC3000-Y-AU	888641	Y	15K		
MPC3000-M-AU	888642	M	15K		
MPC3000-C-AU	888643	C	15K		
MPC3000-M-AU	888666	M	15K		
MPC3000-K-AU	888664	K	20K		
MPC3000-K-NA	841338	K	20K	NA	Ricoh MPC3000
MPC3000-Y-NA	841339	Y	15K	NA	
MPC3000-M-NA	841340	M	15K	NA	
MPC3000-C-NA	841341	C	15K	NA	
MPC3000-M-NA	888638	M	15K	NA	
MPC3000-K-NA	841276	K	20K	NA	Ricoh MPC3000
MPC3501-C	829496	C	15K	/	Ricoh MPC3501
MPC3501-M-NA	841422	M	15K	NA	Ricoh MPC3501
MPC4500-C-JP	625061	C	17K	JP	Ricoh MPC4500
MPC4500-M-JP	634177	M	17K	JP	
MPC4500-Y-JP	646871	Y	17K	JP	
MPC4500-BK-NA	841342	BK	23K	NA	Ricoh MPC4500
MPC4500-Y-NA	841343	Y	17K		
MPC4500-M-NA	841344	M	17K		
MPC4500-Y-UK	884931	Y	17K	UK	Ricoh MPC4500
MPC4500-K-UK	884934	K	23K	UK	
MPC4500-Y-UK	884935	Y	17K	UK	
MPC4500-M-UK	884936	M	17K	UK	
MPC4500-C-UK	884937	C	17K	UK	
MPC4500-M-UK	884944	M	14.17K	UK	
MPC4500-K-EUR	888608	K	23K	EUR	
MPC4500-Y-EUR	888609	Y	17K	EUR	Ricoh MPC4500
MPC4500-M-EUR	888610	M	17K	EUR	
MPC4500-Y-CHN	888633	Y	17K	CHN	Ricoh MPC4500
SP5200-K	400065	K	25K	/	Ricoh SP5200
SP430-BK-NA	821070	BK	21K		

			SP430-Y-NA	821071	Y	24K	NA	Ricoh SPC430DN			
			SP430-M-NA	821072	M	24K					
			SP430-C-NA	821073	C	24K					
			SP430-BK-EUR	821204	BK	21K					
			SP430-Y-EUR	821205	Y	24K					
			SP430-M-EUR	821206	M	24K	EUR	Ricoh SPC430DN			
			SP430-C-EUR	821207	C	24K					
			SP430-Y-EUR	821095	Y	24K					
Q3	 	XEROX	ALX-2605-BK	106R02605	BK	5K*2个	EXP	Xerox Phaser 7100N/DN			
			ALX-2602-C	106R02602	C	4.5K*2个	EXP				
			ALX-2603-M	106R02603	M	4.5K*2个	EXP				
			ALX-2604-Y	106R02604	Y	4.5K*2个	EXP				
			ALX-2599-C	106R02599	C	4.5K	EXP				
			ALX-2600-M	106R02600	M	4.5K	EXP				
			ALX-2601-Y	106R02601	Y	4.5K	EXP				
			ALX-2612-BK	106R02612	BK	5K*2个	ME	Xerox Phaser 7100N/DN			
			ALX-2606-C	106R02606	C	4.5K	ME				
			ALX-2607-M	106R02607	M	4.5K	ME				
			ALX-2608-Y	106R02608	Y	4.5K	ME				
			ALX-1510-BK	106R01510	BK	18K	EXP	Xerox Phaser 6700N/DN			
			ALX-1507-C	106R01507	C	12K	EXP				
			ALX-1508-M	106R01508	M	12K	EXP				
			ALX-1509-Y	106R01509	Y	12K	EXP				
			ALX-1506-BK	106R01506	BK	7.1K	EXP				
			ALX-1503-C	106R01503	C	5K	EXP				
			ALX-1504-M	106R01504	M	5K	EXP				
			ALX-1505-Y	106R01505	Y	5K	EXP	XEROX Phaser 6700N/DN			
			ALX-1526-BK	106R01526	BK	18K	ME				
			ALX-1523-C	106R01523	C	12K	ME				
			ALX-1524-M	106R01524	M	12K	ME				
			ALX-1525-Y	106R01525	Y	12K	ME				
						ALX-2459K	CT202459	BK	5K	JP	Fujixerox docuprint-C3450d
						ALX-2460C	CT202460	C	6k	JP	
						ALX-2461M	CT202461	M	6k	JP	
						ALX-2462Y	CT202462	Y	6k	JP	
					DELL	ALD-5850-C	330-5850	C	12K	WW	Dell5130
						ALD-5843-M	330-5843	M	12K	WW	
						ALD-5852-Y	330-5852	Y	12K	WW	
		ALD-5851-BK	330-5851	BK		9K	US	DELL 5130			
		ALD-5848-C	330-5848	C		6K	US				
		ALD-5845-M	330-5845	M		6K	US				
		ALD-5839-Y	330-5839	Y		6K	US				
			ALE-3T33K	LPC3T33K	BK	4.7K	JP	Fison I P.S6160			
			ALE-3T33C	LPC3T33C	C	5.3K	JP				

Q4



















<b>EPSON</b>	ALE-3T33M	LPC3T33M	M	5.3K	JP	Epson LP-S7160	
	ALE-3T33Y	LPC3T33Y	Y	5.3K	JP		
	ALE-3T35K	LPC3T35K	BK	4.1K	JP		
	ALE-3T35C	LPC3T35C	C	3.7K	JP		
	ALE-3T35M	LPC3T35M	M	3.7K	JP		
	ALE-3T35Y	LPC3T35Y	Y	3.7K	JP		
	<b>NEC</b>	ALN-9014K	PR-L9010C-11	Y	4.5K	JP	NEC MultiWriter-9010
		ALN-9013C	PR-L9010C-12	M	4.5K	JP	
		ALN-9012M	PR-L9010C-13	C	4.5K	JP	
		ALN-9011Y	PR-L9010C-14	BK	5K	JP	
	<b>XEROX</b>	ALX-1439-BK	106R01439	BK	19.8K	EXP	Xerox Phaser 7500N/DN
		ALX-1436-C	106R01436	C	17.8K	EXP	
ALX-1437-M		106R01437	M	17.8K	EXP		
ALX-1438-Y		106R01438	Y	17.8K	EXP		
ALX-1569-BK		106R01569	BK	24K	EXP	Xerox Phaser 7800N/DN	
ALX-1566-C		106R01566	C	17.2K	EXP		
ALX-1567-M		106R01567	M	17.2K	EXP		
ALX-1568-Y		106R01568	Y	17.2K	EXP		
ALX-1563-C		106R01563	C	6K	EXP		
ALX-1564-M		106R01564	M	6K	EXP		
<b>Dell</b>	ALD-6135-BK	330-6135	BK	19K	WW	Dell7130	
	ALD-6142-C	330-6142	C	11K	WW		
	ALD-6143-M	330-6143	M	11K	WW		
	ALD-6144-Y	330-6144	Y	11K	WW		
	ALD-6138-C	330-6138	C	20K	WW		
	ALD-6141-M	330-6141	M	20K	WW		
	ALD-6139-Y	330-6139	Y	20K	WW		





Q3




<b>XEROX</b>	ALX-2605-BK-N	106R02605	BK	5K*2个	EXP	Xerox Phaser 7100N/DN
	ALX-2599-C-N	106R02599	C	4.5K	EXP	
	ALX-2600-M-N	106R02600	M	4.5K	EXP	
	ALX-2601-Y-N	106R02601	Y	4.5K	EXP	
	ALX-2612-BK-N	106R02612	BK	5K*2个	ME	
	ALX-2609-C-N	106R02609	C	4.5K*2个	ME	
	ALX-2610-M-N	106R02610	M	4.5K*2个	ME	
	ALX-2611-Y-N	106R02611	Y	4.5K*2个	ME	
	ALX-2606-C-N	106R02606	C	4.5K	ME	
	ALX-2607-M-N	106R02607	M	4.5K	ME	
	ALX-2608-Y-N	106R02608	Y	4.5K	ME	
	ALX-1510-BK-N	106R01510	BK	18K	EXP	Xerox Phaser 6700N/DN
	ALX-1507-C-N	106R01507	C	12K	EXP	
	ALX-1508-M-N	106R01508	M	12K	EXP	
	ALX-1509-Y-N	106R01509	Y	12K	EXP	
	ALX-1506-BK-N	106R01506	BK	7K	EXP	

			ALX-1503-C-N	106R01503	C	5K	EXP	
			ALX-1504-M-N	106R01504	M	5K	EXP	
			ALX-1505Y-N	106R01505	Y	5K	EXP	
			ALX-1526-BK-N	106R01526	BK	18K	ME	
			ALX-1523-C-N	106R01523	C	12K	ME	Xerox Phaser 6700N/DN
			ALX-1524-M-N	106R01524	M	12K	ME	
			ALX-1525-Y-N	106R01525	Y	12K	ME	
Q4	 	XEROX	ALX-1439-BK-N	106R01439	BK	19.8K	EXP	Xerox Phaser 7500N/DN
			ALX-1436-C-N	106R01436	C	17.8K	EXP	
			ALX-1437-M-N	106R01437	M	17.8K	EXP	
			ALX-1438-Y-N	106R01438	Y	17.8K	EXP	
			ALX-1569-BK-N	106R01569	BK	24K	EXP	Xerox Phaser 7800N/DN
			ALX-1566-C-N	106R01566	C	17.2K	EXP	
			ALX-1567-M-N	106R01567	M	17.2K	EXP	
			ALX-1568-Y-N	106R01568	Y	17.2K	EXP	
			ALX-1563-C-N	106R01563	C	6K	EXP	
		ALX-1564-M-N	106R01564	M	6K	EXP		
		ALX-1565-Y-N	106R01565	Y	6K	EXP		
		Dell	ALD-6135-BK-N	330-6135	BK	19K	WW	Dell7130
			ALD-6142-C-N	330-6142	C	11K	WW	
			ALD-6143-M-N	330-6143	M	11K	WW	
			ALD-6144-Y-N	330-6144	Y	11K	WW	
			ALD-6138-C-N	330-6138	C	20K	WW	
			ALD-6141-M-N	330-6141	M	20K	WW	
		ALD-6139-Y-N	330-6139	Y	20K	WW		
OEM	 	LENOVO	LD205BK	LD205BK	BK	4.5K	CHN	Lenovo CS2010DW
		RICOH	SP-C252/407561	SP-C252/407561	BK	4.5K	EX.JPN	Ricoh SP C252DN/252SF
			SP-C220/406052	SP-C220/406052	BK	2K	WW(EX.JPN)	Ricoh Aficio SP C220s/222/240dn/240sf
			SP-C250/407729/600568	SP-C250/407729/600568	BK	2.0K	WW	Ricoh SP C250
			SP-C252H/407724	SP-C252H/407724	BK	6.5K	EX.JPN	Ricoh SP C252DN/252SF
			SP-C310/308504	SP-C310/308504	BK	2.2K	WW	Ricoh Aficio SP C311N/312DN/C231SF/IPSiO SPC310/C232SF/C242DN/C340DN/342DN/C342 / C342M / C341/C251SF
			SP-C310H/406475	SP-C310H/406475	BK	6.5K	WW	Ricoh Aficio SP C311N/312DN/C231SF/IPSiO SPC310/C232SF/C242DN/342DN/C342 / C342M / C341/C251SF
			SP-300	SP-300	BK	1.5K	WW(EX.JPN)	Ricoh SP 300
			SP-3400H/406465	SP-3400H/406465	BK	5K	WW(EX.JPN)	Ricoh Aficio SP3400N/3400SF/3410SF/3410DN
			SP-3400LC/406464	SP-3400LC/406464	BK	2.5K	WW(EX.JPN)	/3500SF/3510DN/3500N/3510SF
SP-3500X/406989	SP-3500X/406989	BK	6.4K	WW(EX.JPN)	Ricoh Aficio SP3500SF/3510DN/3500N/3510SF			
OEM	 	LENOVO	LD205C	LD205C	C	4K	CHN	Lenovo CS2010DW
		RICOH	SP-C252/407562	SP-C252/407562	C	4K	EX.JPN	Ricoh SP C252DN/252SF
			SP-C220/406053	SP-C220/406053	C	2K	WW(EX.JPN)	Ricoh Aficio SP C220s/222/240dn/240sf
			SP-C250/407730/600569	SP-C250/407730/600569	C	1.6K	WW	Ricoh SP C250
			SP-C252H/407725	SP-C252H/407725	C	6K	EX.JPN	Ricoh SP C252DN/252SF

			SP-C310/308505 SP-C310H/406476	SP-C310/308505 SP-C310H/406476	C C	2.2K 6K	WW WW	Ricoh Aficio SP C311N/312DN/C231SF/IPSiO SPC310/C232SF/C242DN/C340DN/342DN/C342 / C342M / C341/C251SF Ricoh Aficio SP C311N/312DN/C231SF/IPSiO SPC310/C232SF/C242DN/342DN/C342 / C342M / C341/C251SF
<b>OEM</b>  		<b>LENOVO</b>  <b>RICOH</b>	LD205M SP-C252/407563 SP-C220/406054 SP-C250/407731/600570 SP-C252H/407726 SP-C310/308506 SP-C310H/406477	LD205M SP-C252/407563 SP-C220/406054 SP-C250/407731/600570 SP-C252H/407726 SP-C310/308506 SP-C310H/406477	M M M M M M	4K 4K 2K 1.6K 6K 2.2K 6K	CHN EX.JPN WW EX.JPN WW WW	Lenovo CS2010DW Ricoh SP C252DN/252SF Ricoh Aficio SP C220s/222/240dn/240sf Ricoh SP C250 Ricoh SP C252DN/252SF Ricoh Aficio SP C311N/312DN/C231SF/IPSiO SPC310/C232SF/C242DN/C340DN/342DN/C342 / C342M / C341/C251SF Ricoh Aficio SP C311N/312DN/C231SF/IPSiO SPC310/C232SF/C242DN/342DN/C342 / C342M / C341/C251SF
<b>OEM</b>  		<b>LENOVO</b>  <b>RICOH</b>	LD205Y SP-C252/407564 SP-C220/406055 SP-C250/407732/600571 SP-C252H/407727 SP-C310/308507 SP-C310H/406478	LD205Y SP-C252/407564 SP-C220/406055 SP-C250/407732/600571 SP-C252H/407727 SP-C310/308507 SP-C310H/406478	Y Y Y Y Y Y	4K 4K 2K 1.6K 6K 2.2K 6K	CHN EX.JPN WW EX.JPN WW WW	Lenovo CS2010DW Ricoh SP C252DN/252SF Ricoh Aficio SP C220s/222/240dn/240sf Ricoh SP C250 Ricoh SP C252DN/252SF Ricoh Aficio SP C311N/312DN/C231SF/IPSiO SPC310/C232SF/C242DN/C340DN/342DN/C342 / C342M / C341/C251SF Ricoh Aficio SP C311N/312DN/C231SF/IPSiO SPC310/C232SF/C242DN/342DN/C342 / C342M / C341/C251SF
<b>OEM</b>  		<b>RICOH</b>	SP-4500/512560/Drum SP-4500/407324/Drum SP-6400/512684Drum	SP-4500/512560/Drum SP-4500/407324/Drum SP-6400/512684Drum	Drum Drum Drum	20K 20K 25K	JP WW(EX.JPN) WW	Ricoh SP 4510SF/4510/4500/3610SF/3610 Ricoh SP 3600SF/3610SF/3600DN/4510SF/4510DN/4510SF Ricoh SP 6440/6440M/6430/6430M/6420/6420M/6410/6450
<b>OEM</b>  		<b>LENOVO</b>  <b>RICOH</b>	LD228 SP-100L/407165 SP-150LE/407971 SP-150HE/408010 SP-200C/430707 SP-201H/407258 SP-2100 SP-311HC SP-110C	LD228 SP-100L/407165 SP-150LE/407971 SP-150HE/408010 SP-200C/430707 SP-201H/407258 SP-2100 SP-311HC SP-110C	BK BK BK BK BK BK BK K	1.5K 1.2K 0.7K 1.5K 2.6K 2.6K 2K 6.4K 2K	CHN WW(EX.JPN) WW WW WW WW JP WW(EX.JPN) WW(EX.JPN)	Lenovo LJ2208W /Lenovo LJ2208/M7208W/M7208 Ricoh Aficio SP 100e/100SU/100SF 112/112SF/112SU Ricoh SP 150/150SU/150w/150Suw Ricoh SP 200/201/200N/210/212Nw/202SF/201SF/200SF/202S/201S/200S/210SF/210SU/SP 220Nw/SP 220SFNw/SP 220SNw Ricoh SP 201Nw/201/204SFNw/204SN/204SF/213Nw/213SNw/203SFN/203SF/200N/200/202SF/201SF/201S/202S/SP 211SF/SP 211SU/SP 211/SP 220Nw/SP 220SFNw/SP 220SNw Ricoh SP 2100L Ricoh SP 310SFNw/ SP 310DNw/SP 311SFN/SP 311DN/SP 311DNw/SP 311SFNw/ SP 320DN/SP 320SN/SP 320SFN/SP 325DNw/SP 325SFNw Ricoh SP 111/111SF/111SU

			SP-310C	SP-310C	BK	3.5K	WW(EX..JPN )	Ricoh SP 311DNw/311DN/SP 311SFN/SP 311SFNw Ricoh SP 310SFNw/ SP 310DNw Ricoh SP 310SFN/310DN Ricoh SP 312SFNw/SP 312DNw// SP 320DN/SP 320SN/SP 320SFN/SP 325DNw/SP 325SFNw
<b>OEM</b>   	<b>RICOH</b>		SP-4500L/407323/407321	SP-4500L/407323/407321	BK	3K	WW(EX..JPN )	Ricoh SP 3600SF/3610SF/3600DN/4510SF/4510
			SP-4500/407340/407319	SP-4500/407340/407319	BK	6K	WW(EX..JPN )	
			SP-4500H/407318/407316	SP-4500H/407318/407316	BK	12K	WW(EX..JPN )	Ricoh SP 4510DN/4510SF
			SP-4500L/600546	SP-4500L/600546	BK	3K	JP	
			SP-4500/600545	SP-4500/600545	BK	6K	JP	Ricoh SP 4510SF/4510/4500/3610SF/3610
			SP-4500H/600544	SP-4500H/600544	BK	10K	JP	
			MP-401/841886	MP-401/841886	BK	10.4K	EX.JP	Ricoh SP 4520DN/MP 401SPF/MP 402SPF
			SP-6400/600573	SP-6400/600573	BK	5K	WW	Ricoh SP 6440/6440M/
			SP-6400H/600572	SP-6400H/600572	BK	10K	WW	6430/6430M/6420/6420M/6410/6450
<b>RST-OEM</b> <b>RST-</b> <b>KYOCER</b> <b>I/II/III</b>	 	<b>Fujitsu</b>	LB320B	LB320B	BK	12K	JP	Fujitsu 9381
			LB321B	LB321B	BK	12K	JP	Fujitsu 9321
			ALK-TK-130	TK-130	BK	7.2K	EUR	Kyocera FS1028MFP/FS1028MFP/DP/FS-1128MFP/FS1128/DP/FS-1300D/FS-1300DN/FS-1350DN
					BK	12K	EUR	
			ALK-TK-131	TK-131	BK	7.2K	JAPAN	
					BK	2.3K	JAPAN	
			ALK-TK-132	TK-132	BK	7.2K	USA	
			ALK-TK-133	TK-133	BK	7.2K	CHN	
			ALK-TK-134	TK-134	BK	7.2K	ASIA(Non JP/CHN)	
			ALK-TK-135	TK-135	BK	7.2K	EUR	Kyocera KM-2810/2820
			ALK-TK-137	TK-137	BK	7.2K	USA	
			ALK-TK-140	TK-140	BK	4K	EUR	Kyocera FS-1100
					BK	12K	EUR	
			ALK-TK-142	TK-142	BK	4K	USA	
			ALK-TK-143	TK-143	BK	4K	CHINA	
			ALK-TK-160	TK-160	BK	2.5K	EUR	Kyocera FS-1120
					BK	5K	EUR	
			ALK-TK-162	TK-162	BK	2.5K	USA	
			ALK-TK-164	TK-164	BK	2.5K	ASIA(Non JP/CHN)	
			ALK-TK-164K	TK-164K	BK	2.5K	KOR	
			ALK-TK-170	TK-170	BK	7.2K	EUR	Kyocera FS1320D/1370DN
					BK	14K	EUR	
			ALK-TK-172	TK-172	BK	7.2K	USA	
			ALK-TK-173	TK-173	BK	7.2K	CHN	
	ALK-TK-174	TK-174	BK	7.2K	ASIA(Non JP/CHN)			
	ALK-TK-310	TK-310	BK	12K	EUR	Kyocera FS-2000D/3900DN/4000DN		
			BK	18K	EUR			
	ALK-TK-311	TK-311	BK	12K	JAPAN			
	ALK-TK-312	TK-312	BK	12K	USA			
	ALK-TK-313	TK-313	BK	12K	CHN			




ALK-TK-314	TK-314	BK	12K	ASIA(Non JP CHN)	Kyocera FS-3900DN/4000DN
ALK-TK-320	TK-320	BK	15K	EUR	
		BK	25K	EUR	
ALK-TK-322	TK-322	BK	15K	USA	
ALK-TK-323	TK-323	BK	15K	CHINA	
ALK-TK-324	TK-324	BK	15K	ASIA(Non JP CHN)	Kyocera FS-4000DN
ALK-TK-330	TK-330	BK	20K	EUR	
		BK	30K	EUR	
ALK-TK-331	TK-331	BK	20K	JAPAN	
ALK-TK-332	TK-332	BK	20K	USA	
ALK-TK-334	TK-334	BK	20K	ASIA(Non JP CHN)	Kyocera FS-2020D, FS-2020DN
ALK-TK-340	TK-340	BK	12K	EUR	
		BK	18K	EUR	
ALK-TK-341	TK-341	BK	12K	JAPAN	
ALK-TK-342	TK-342	BK	12K	USA	
ALK-TK-343	TK-343	BK	12K	CHN	Kyocera FS-3920DN /3925DN
ALK-TK-344	TK-344	BK	12K	ASIA(Non JP CHN)	
ALK-TK-350	TK-350	BK	15K	EUR	
		BK	25.5K	EUR	
ALK-TK-351	TK-351	BK	15K	JAPAN	
ALK-TK-352	TK-352	BK	15K	USA	Kyocera FS-4020DN
ALK-TK-353	TK-353	BK	15K	CHINA	
ALK-TK-354	TK-354	BK	15K	ASIA(Non JP CHN)	
ALK-TK-360	TK-360	BK	20K	EUR	
		BK	30K	EUR	
ALK-TK-361	TK-361	BK	20K	JAPAN	Kyocera KM-2050 /1650/2035/ 2020/1635/1620
ALK-TK-362	TK-362	BK	20K	USA	
ALK-TK-363	TK-363	BK	20K	CHINA	
ALK-TK-364	TK-364	BK	20K	ASIA(Non JP CHN)	
ALK-TK-410	TK-410	BK	15K	EUR	
ALK-TK-435	TK-435	BK	15K	EUR	
ALK-TK-437	TK-437	BK	15K	USA	
ALK-TK-438	TK-438	BK	15K	CHINA	
ALK-TK-439	TK-439	BK	15K	ASIA(Non JP CHN)	Kyocera FS-6950DN
ALK-TK-440	TK-440	BK	15K	EUR	
ALK-TK-442	TK-442	BK	15K	USA	
ALK-TK-450	TK-450	BK	15K	EUR	
ALK-TK-451	TK-451	BK	20K	JAPAN	
ALK-TK-452	TK-452	BK	15K	USA	
ALK-TK-453	TK-453	BK	15K	CHINA	
ALK-TK-454	TK-454	BK	15K	ASIA(Non JP CHN)	



Kyocera

ALK-TK-475	TK-475	BK	15K	EUR	Kyocera FS-6025 MFP/ 6030MFP/6525MFP/6530MFP
ALK-TK-477	TK-477	BK	15K	USA	
ALK-TK-478	TK-478	BK	15K	CHINA	
ALK-TK-675	TK-675	BK	20K	EUR	Kyocera KM-3040 /2540
ALK-TK-677	TK-677	BK	20K	USA	Kyocera KM-2540
ALK-TK-678	TK-678	BK	24K	CHINA	Kyocera KM-2560
ALK-TK-679	TK-679	BK	20K	ASIA(Non JP CHN)	Kyocera KM-3060
ALK-TK-685	TK-685	BK	20K	EUR	Kyocera TASKalfa 300i
ALK-TK-710	TK-710	BK	40K	EUR	Kyocera FS-9530DN /9130DN
ALK-TK-712	TK-712	BK	40K	USA	
ALK-TK-713	TK-713	BK	40K	CHINA	
ALK-TK-714	TK-714	BK	40K	ASIA(Non JP CHN)	
ALK-TK-715	TK-715	BK	34K	EUR	Kyocera KM-3050/4050/5050
ALK-TK-717	TK-717	BK	34K	USA	
ALK-TK-718	TK-718	BK	34K	CHINA	
ALK-TK-719	TK-719	BK	34K	ASIA(Non JP CHN)	
ALK-TK-725	TK-725	BK	34K	EUR	Kyocera 420i/520i
ALK-TK-144	TK-144	BK	4K	South-East ASIA/AUS	Kyocera FS-1100
ALK-TK-333	TK-333	BK	20K	CHN	Kyocera FS-1100
ALK-TK-420	TK-420	BK	15K	EUR	Kyocera KM-2550
ALK-TK-430	TK-430	BK	7.2K	EUR	Kyocera KM-1648
ALK-TK-454K	TK-454K	BK	15K	KOR	Kyocera FS-6975DN/ 6975DNG
ALK-TK-655	TK-655	BK	47K	EUR	Kyocera KM-6030/8030
ALK-TK-665	TK-665	BK	55K	EUR	Kyocera TASKalfa-620/820
ALK-TK-689K	TK-689K	BK	20K	KOR	Kyocera TASKalfa-300i
ALK-TK-729K	TK-729K	BK	34K	KOR	Kyocera TASKalfa-420i/520i
ALK-TK-120	TK-120	BK	7.2K	EUR	Kyocera FS-1030D/1030DN
ALK-TK-122	TK-122	BK	7.2K	USA	Kyocera FS-1030D/1030DN
ALK-TK-163	TK-163	BK	2.5K	CHN	Kyocera FS-1120
ALK-TK-174K	TK-174K	BK	7.2K	KOR	Kyocera FS-1320DB
		BK	2.3K	KOR	
ALK-TK-443	TK-443	BK	15K	CHN	KyoceraFS-6950DN
ALK-TK-479	TK-479	BK	15K	AUS	KyoceraFS-6025MFP / 6030MFP / 6525MFP / 6530MFP
ALK-TK-479K	TK-479K	BK	15K	KOR	KyoceraFS-6025MFP / 6025MFPG / 6025MFP / 6030MFPG / 6525MFPG / 6530MFPG
ALK-TK-500	TK-500	BK	8K	EUR	Kyocera FS-C5016N
		C	8K	EUR	
		M	8K	EUR	
		Y	8K	EUR	
ALK-TK-510	TK-510	BK	8K	EUR	Kyocera FS-C5020N/ C5025N/C5030N
		C	8K	EUR	
		M	8K	EUR	
		Y	8K	EUR	






ALK-TK-6709K	TK-6709K	BK	84K	KOR	Kyocera FS-6500i / 6500iG / 8000i / 8000iG
ALK-TK-7109K	TK-7109K	BK	18K	KOR	Kyocera FS-3010i / 3010iG
ALK-TK-7109K	TK-7109K	BK	35K	KOR	
ALK-TK-7209K	TK-7209K	BK	32K	KOR	Kyocera FS-3510i / 3510iG
ALK-TK-6307	TK-6307	BK	35K	USA	Kyocera FS-3500i / 4500i / 5500i
ALK-TK-592	TK-592	BK	7K	USA	Kyocera FS-C2026MFP Kyocera FS-C2126MFP/C2526MFP/C2626MFP/C5250DN
		C	5K		
		M	5K		
		Y	5K		
ALK-TK-593	TK-593	BK	7K	CHN	
		C	5K		
		M	5K		
		Y	5K		
ALK-TK-5135	TK-5135	BK	10K	EUR	
		C	5K		
		M	5K		
		Y	5K		
ALK-TK-8305	TK-8305	BK	25K	EUR	
		C	15K		
		M	15K		
		Y	15K		
ALK-TK-8307	TK-8307	BK	25K	USA	
		C	15K		
		M	15K		
		Y	15K		
ALK-TK-8309	TK-8309	BK	25K	ASIA(Non JPN\CHN)	
		C	15K		
		M	15K		
		Y	15K		
ALK-TK-580	TK-580	BK	3.5K	EUR	Kyocera FS-C5150DN / C5150DNG/P6021
		C	2.8K	EUR	
		M	2.8K	EUR	
		Y	2.8K	EUR	
ALK-TK-582	TK-582	BK	3.5K	USA	Kyocera FS-C5150DN/P6021
		C	2.8K	USA	
		M	2.8K	USA	
		Y	2.8K	USA	
ALK-TK-583	TK-583	BK	3.5K	CHN	
		C	2.8K	CHN	
		M	2.8K	CHN	
		Y	2.8K	CHN	
ALK-TK-584	TK-584	BK	3.5K	AUS	
		C	2.8K	AUS	
		M	2.8K	AUS	
		Y	2.8K	AUS	
		BK	3.5K	KOR	

ALK-TK-584K	TK-584K	C	2.8K	KOR	Kyocera FS-C5150DN/ C5150DNG/P6021		
		M	2.8K	KOR			
		Y	2.8K	KOR			
		ALK-TK-590	TK-590	BK	7K	EUR	Kyocera FS-C2026MFP/ C2126MFP/C2526MFP /C2626MFP/ C5250DN/P6026/M6526
				C	5K	EUR	
				M	5K	EUR	
		ALK-TK-590	TK-590	Y	5K	EUR	
				BK	14	EUR	
				C	10	EUR	
		ALK-TK-591	TK-591	M	10	EUR	
				Y	10	EUR	
				BK	7K	JPN	
		ALK-TK-591	TK-591	C	5K	JPN	
				M	5K	JPN	
				Y	5K	JPN	
		ALK-TK-594	TK-594	BK	7K	AUS	KyoceraFS-C2026MFP/C2126MFP/ C2526MFP/C2626MFP/ C5250DN/P6026/M6526
				C	5K	AUS	
				M	5K	AUS	
		ALK-TK-594	TK-594	Y	5K	AUS	
				BK	7K	KOR	
				C	5K	KOR	
		ALK-TK-594K	TK-594K	M	5K	KOR	
				Y	5K	KOR	
				BK	30K	EUR	
ALK-TK-8600	TK-8600	C	20K	EUR	Kyocera FS-C8600DN/C8650DN		
		M	20K	EUR			
		Y	20K	EUR			
ALK-TK-1100	TK-1100	BK	2.1K	EUR	Kyocera®FS-1110/1024/1124MFP		
		ALK-TK-1102	TK-1102	BK		2.1K	USA
		ALK-TK-1103	TK-1103	BK		2.1K	CHN
				BK		1K	CHN
		ALK-TK-1130	TK-1130	BK	3K	EUR	Kyocera FS-1130MFP, ECOSYS M2030dn/FS-1030MFP/ECOSYS M2030dn PN/ECOSYS M2530dn/FS-1030MFP/DP
		ALK-TK-1133	TK-1133	BK	3K	CHN	Kyocera®FS-1030/1130MFP
		ALK-TK-1134	TK-1134	BK	3K	ASIA	Kyocera®ECOSYS M2530DN/M2030DN PN/M2030DN
		ALK-TK-1140	TK-1140	BK	7.2K	EUR	Kyocera FS-1035MFP/DP/FS-1135MFP/ECOSYS M2535dn/ECOSYS M2035dn
				BK	14.4K	EUR	
		ALK-TK-1141	TK-1141	BK	7.2K	JPN	Kyocera®P2135dn/FS-1370DN/LS-1028/1128/1035/1135MFP
		ALK-TK-1142	TK-1142	BK	7.2K	USA	Kyocera FS-1035MFP/1135MFP
		ALK-TK-1143	TK-1143	BK	7.2K	CHN	
		ALK-TK-1144	TK-1144	BK	7.2K	ASIA	
		ALK-TK-1147	TK-1147	BK	12K	USA	Kyocera FS-1035/FS-1135DN
		ALK-TK-1104	TK-1104	BK	2.1K	South-East ASIA/AUS	Kyocera FS-1110/FS-1024/1124MFP
		ALK-TK-1104K	TK-1104K	BK	2.1K	KOR	
ALK-TK-1144K	TK-1144K	BK	7.2K	KOR	Kyocera FS-1035MFP/DP/FS-1135MFP		
T-2309C	T-2309C	K	17.5K	CHN	Toshiba e-Studio2309A/2309A/2809A		
T-2309CS	T-2309CS	K	6K	CHN			

RST-OEM  
RST-  
KYOCER  
IV



sample pictures



Kyocera

PCB-B52




TOSHIBA

T-2309E SAMPLE!	T-2309E	K	17.5K	EUR	Toshiba e-Studio2309A/2309H/2309K
T-2309U SAMPLE!	T-2309U	K	17.5K	NA	
T-2505C	T-2505C	K	12K	CHN	
T-2505E SAMPLE!	T-2505E	K	12K	EUR	Toshiba e-Studio 2505/2505H/2505F
T-2505U SAMPLE!	T-2505U	K	12K	NA	
T-2507C	T-2507C	K	12K	CHN	
T-2507CS	T-2507CS	K	6K	CHN	
T-2507D SAMPLE!	T-2507D	K	12K	AP	Toshiba e-Studio 2006/2306/2506/2307/2507
T-2507E SAMPLE!	T-2507E	K	12K	EUR	
T-2507T SAMPLE!	T-2507T	K	12K	TW	
T-2507U SAMPLE!	T-2507U	K	12K	NA	
T-2802C	T-2802C	K	17.5K	CHN	
T-2802CS SAMPLE!	T-2802CS	K	6K	CHN	
T-2802E SAMPLE!	T-2802E	K	17.5K	EUR	Toshiba e-Studio2802A/2802AM/2802AF
T-2802P SAMPLE!	T-2802P	K	17.5K	AP	
T-2802U SAMPLE!	T-2802U	K	17.5K	NA	
T-5508C	T-5508C	K	80K	CHN	
T-5508P SAMPLE!	T-5508P	K	80K	AP	Toshiba e-Studio 5508A/6508A/7508A/8508A
T-5508U SAMPLE!	T-5508U	K	80K	NA	
T-FC30CC SAMPLE!	T-FC30CC	C	33.6K	CHN	
T-FC30CK SAMPLE!	T-FC30CK	K	38.4K	CHN	
T-FC30CM SAMPLE!	T-FC30CM	M	33.6K	CHN	
T-FC30CY SAMPLE!	T-FC30CY	Y	33.6K	CHN	
T-FC30DC SAMPLE!	T-FC30DC	C	33.6K	AP	
T-FC30DK SAMPLE!	T-FC30DK	K	38.4K	AP	
T-FC30DM SAMPLE!	T-FC30DM	M	33.6K	AP	
T-FC30DY SAMPLE!	T-FC30DY	Y	33.6K	AP	Toshiba e-Studio 2051C/2050C/2551C/2550C
T-FC30EC SAMPLE!	T-FC30EC	C	33.6K	EUR	
T-FC30EK SAMPLE!	T-FC30EK	K	38.4K	EUR	
T-FC30EM SAMPLE!	T-FC30EM	M	33.6K	EUR	
T-FC30EY SAMPLE!	T-FC30EY	Y	33.6K	EUR	
T-FC30UC SAMPLE!	T-FC30UC	C	33.6K	NA	
T-FC30UK SAMPLE!	T-FC30UK	K	38.4K	NA	
T-FC30UM SAMPLE!	T-FC30UM	M	33.6K	NA	
T-FC30UY SAMPLE!	T-FC30UY	Y	33.6K	NA	
T-FC505CC SAMPLE!	T-FC505CC	C	25K	CHN	
T-FC505CCS SAMPLE!	T-FC505CCS	C	3K	CHN	
T-FC505CK SAMPLE!	T-FC505CK	K	32K	CHN	
T-FC505CKS SAMPLE!	T-FC505CKS	K	7K	CHN	Toshiba e-Studio 2000A/2500AC/2505AC/3005AC/3505AC/4505AC/5005AC
T-FC505CM SAMPLE!	T-FC505CM	M	25K	CHN	
T-FC505CMS SAMPLE!	T-FC505CMS	M	3K	CHN	
T-FC505CY SAMPLE!	T-FC505CY	Y	25K	CHN	
T-FC505CYS SAMPLE!	T-FC505CYS	Y	3K	CHN	
T-FC505UC SAMPLE!	T-FC505UC	C	25K	NA	
T-FC505UK SAMPLE!	T-FC505UK	K	32K	NA	Toshiba e-Studio 2000A/2500AC/2505AC/3005AC/3505AC/4505AC/5005AC
T-FC505UM SAMPLE!	T-FC505UM	M	25K	NA	
T-FC505UY SAMPLE!	T-FC505UY	Y	25K	NA	
T-FC50CC SAMPLE!	T-FC50CC	C	33.6K	CHN	
T-FC50CK SAMPLE!	T-FC50CK	K	38.4K	CHN	
T-FC50CM SAMPLE!	T-FC50CM	M	33.6K	CHN	
T-FC50CY SAMPLE!	T-FC50CY	Y	33.6K	CHN	

		T-FC50DC SAMPLE!	T-FC50DC	C	33.6K	AP	Toshiba e-Studio 2505AC/3005AC/3505AC/ 4505AC/5005AC	
		T-FC50DK SAMPLE!	T-FC50DK	K	38.4K	AP		
		T-FC50DM SAMPLE!	T-FC50DM	M	33.6K	AP		
		T-FC50DY SAMPLE!	T-FC50DY	Y	33.6K	AP		
		T-FC50EC SAMPLE!	T-FC50EC	C	33.6K	EUR		
		T-FC50EK SAMPLE!	T-FC50EK	K	38.4K	EUR		
		T-FC50EM SAMPLE!	T-FC50EM	M	33.6K	EUR		
		T-FC50EY SAMPLE!	T-FC50EY	Y	33.6K	EUR		
		T-FC50UC SAMPLE!	T-FC50UC	C	33.6K	NA		
		T-FC50UK SAMPLE!	T-FC50UK	K	38.4K	NA		
		T-FC50UM SAMPLE!	T-FC50UM	M	33.6K	NA		
		T-FC50UY SAMPLE!	T-FC50UY	Y	33.6K	NA		
		T-FC556CC SAMPLE!	T-FC556CC	C	36K	CHN		Toshiba e-Studio 2555C/3555C/4555C/5055C
		T-FC556CK SAMPLE!	T-FC556CK	K	100K	CHN		
		T-FC556CM SAMPLE!	T-FC556CM	M	36K	CHN		
		T-FC556CY SAMPLE!	T-FC556CY	Y	36K	CHN		
		T-FC556PC SAMPLE!	T-FC556PC	C	36K	AP		
		T-FC556PK SAMPLE!	T-FC556PK	K	100K	AP		
		T-FC556PM SAMPLE!	T-FC556PM	M	36K	AP		
		T-FC556PY SAMPLE!	T-FC556PY	Y	36K	AP		
		T-FC556UC	T-FC556UC	C	36K	NA		
		T-FC556UK	T-FC556UK	K	100K	NA		
		T-FC556UM	T-FC556UM	M	36K	NA		
		T-FC556UY	T-FC556UY	Y	36K	NA		
		T-3008C SAMPLE!	T-3008C SAMPLE!	K	43.9K	CHN	Toshiba e-Studio 2508A/3008A/3008AG/3508A/ 3508AG/4508/4508AG/5008A	
		T-3008P SAMPLE!	T-3008P SAMPLE!	K	43.9K	AP		
		T-3008U SAMPLE!	T-3008U SAMPLE!	K	43.9K	NA		
		T-5070C SAMPLE!	T-5070C SAMPLE!	K	43.9K	CHN		Toshiba e-Studio 257/307/257s/307sd/357/457/ 357s/457s/457s/507
		T-5070CM	T-5070CM	K	12K	CHN		
		T-5070E SAMPLE!	T-5070E SAMPLE!	K	43.9K	EUR		
		T-5070T SAMPLE!	T-5070T SAMPLE!	K	43.9K	TW		
		T-5070U SAMPLE!	T-5070U SAMPLE!	K	43.9K	NA		
		ALK-TK1200	TK-1200	K	3K	EUR	Kyocera ECOSYS P2335d/M2835dw	
		ALK-TK1150	TK-1150	K	3K	EUR	Kyocera ECOSYS M2135dn/M2635dn/M2735dw/P2235dn/dw	
		ALK-TK1152	TK-1152	K	3K	NA/LA	Kyocera ECOSYS M2635dw	
		ALK-TK1153	TK-1153	K	3K	CHN	Kyocera ECOSYS P2235dn/dw	
		ALK-TK1154	TK-1154	K	3K	AU		
		ALK-TK1156	TK-1156	K	3K	TW	Kyocera ECOSYS P2235dn	
		ALK-TK1160	TK-1160	K	7.2K	EUR	Kyocera ECOSYS P2040dn/P2040dw	
		ALK-TK1161	TK-1161	K	7.2K	JP	Kyocera ECOSYS P2040dw	
		ALK-TK1162	TK-1162	K	7.2K	NA/LA		
		ALK-TK1164	TK-1164	K	7.2K	AU		
		ALK-TK1166	TK-1166	K	7.2K	TW	Kyocera Ecosys P2040dn/P2040dw	
		ALK-TK1168K	TK-1168K	K	7.2K	KOR		
		ALK-TK1170	TK-1170	K	7.2K	EUR		
		ALK-TK1172	TK-1172	K	7.2K	NA	Kyocera ECOSYS M2040dn/M2540dn/M2640idw	
		ALK-TK1174	TK-1174	K	7.2K	AU		
		ALK-TK1175	TK-1175	K	12K	LA	Kyocera ECOSYS M2040dn/L,M2640idw/L	
		ALK-TK1176	TK-1176	K	7.2K	TW	Kyocera ECOSYS M2540dn	
		ALK-TK1178	TK-1178	K	7.2K	AP	Kyocera Ecosys M2040dn/M2540dn/M2640idw	

### PCB-B53



### B48



Kyocera

ALK-TK1178K	TK-1178K	K	7.2K	KOR	Kyocera Ecosys M2640idw
ALK-TK1183	TK-1183	K	3K	CHN	Kyocera ECOSYS M2135dn/M2635dn
ALK-TK1184	TK-1184	K	3K	AU	Kyocera ECOSYS M2635dn/M2735dw
ALK-TK1186	TK-1186	K	3K	TW	Kyocera ECOSYS M2635dn
ALK-TK1188K	TK-1188K	K	3K	KOR	
ALK-TK1196	TK-1196	K	3K	TW	Kyocera ECOSYS P2230DN
ALK-TK3060	TK-3060	K	14.5K	EUR	KYOCERA ECOSYS M3145idn/3645idn
ALU-PK1010	PK-1010	K	3K	EUR	Utax P-3521MFP/3527W MFP/3522DW
ALU-PK1011	PK-1011	K	7.2K	EUR	Utax P-4020DN/4020DW

UTAX


ALK-TK3160	TK-3160	K	12.5K	EUR	Kyocera ECOSYS P3055dn/ P3060dn/P3050dn/P3045dn
ALK-TK3161	TK-3161	K	12.5K	JP	Kyocera ECOSYS P3045dn/P3060dn
ALK-TK3162	TK-3162	K	12.5K	NA	Kyocera Ecosys P3045dn/P3050dn/P3055dn/P3060dn
ALK-TK3164	TK-3164	K	12.5K	AU	
ALK-TK3166	TK-3166	K	12.5K	TW	Kyocera ECOSYS P3045dn
ALK-TK3170	TK-3170	K	15.5K	EUR	Kyocera ECOSYS P3055dn/P3060dn/P3050dn
ALK-TK3172	TK-3172	K	15.5K	NA	Kyocera Ecosys P3050dn/P3055dn/P3060dn
ALK-TK3174	TK-3174	K	15.5K	AU	
ALK-TK3175K	TK-3175K	K	15.5K	KOR	Kyocera Ecosys P3050dn
ALK-TK3176	TK-3176	K	15.5K	TW	
ALK-TK3182	TK-3182	K	21K	NA	Kyocera Ecosys P3055dn
ALK-TK3190	TK-3190	K	25K	EUR	Kyocera ECOSYS P3055dn/ECOSYS P3060dn
ALK-TK3191	TK-3191	K	25K	JP	Kyocera ECOSYS P3060dn
ALK-TK3192	TK-3192	K	25K	NA	Kyocera Ecosys P3055dn/P3060dn
ALK-TK3194	TK-3194	K	25K	AU	
ALK-TK3196	TK-3196	K	25K	TW	Kyocera ECOSYS P3060dn
ALU-PK3010	PK-3010	K	12.5K	EUR	Utax P-4531DN/5031DN/6031DN
ALU-PK3011	PK-3011	K	15.5K	EUR	Utax P-5031DN/6031DN
ALU-PK3012	PK-3012	K	25K	EUR	Utax P-6031DN

Kyocera


UTAX

ALK-TK5220K	TK-5220K	K	1.2K	EUR	Kyocera ECOSYS M5521cdw/P5021cdw/P5021cdn
ALK-TK5220C	TK-5220C	C	1.2K	EUR	
ALK-TK5220M	TK-5220M	M	1.2K	EUR	
ALK-TK5220Y	TK-5220Y	Y	1.2K	EUR	Kyocera Ecosys P5021cdn/P5021cdw/M5521cdn/M5521cdw
ALK-TK5222K	TK-5222K	K	1.2K	NA	
ALK-TK5222C	TK-5222C	C	1.2K	NA	
ALK-TK5222M	TK-5222M	M	1.2K	NA	Kyocera Ecosys P5021cdn/P5021cdw/M5521cdn/M5521cdw
ALK-TK5222Y	TK-5222Y	Y	1.2K	NA	
ALK-TK5223K	TK-5223K	K	1.2K	CHN	Kyocera ECOSYS P5021cdn/P5021cdw
ALK-TK5223C	TK-5223C	C	1.2K	CHN	
ALK-TK5223M	TK-5223M	M	1.2K	CHN	
ALK-TK5223Y	TK-5223Y	Y	1.2K	CHN	
ALK-TK5224K	TK-5224K	K	1.2K	AU/India	Kyocera ECOSYS M5521cdw/P5021cdw/P5021cdn
ALK-TK5224C	TK-5224C	C	1.2K	AU/India	
ALK-TK5224M	TK-5224M	M	1.2K	AU/India	
ALK-TK5224Y	TK-5224Y	Y	1.2K	AU/India	
ALK-TK5224KK	TK-5224KK	K	1.2K	KOR	
ALK-TK5224KC	TK-5224KC	C	1.2K	KOR	
ALK-TK5224KM	TK-5224KM	M	1.2K	KOR	
ALK-TK5224KY	TK-5224KY	Y	1.2K	KOR	
ALK-TK5230C	TK-5230C	C	2.2K	EUR	
ALK-TK5230K	TK-5230K	K	2.6K	EUR	

B49







B50





Kyocera

ALK-TK5230M	TK-5230M	M	2.2K	EUR	Kyocera ECOSYS P5021cdn/P5021cdw	
ALK-TK5230Y	TK-5230Y	Y	2.2K	EUR		
ALK-TK5232K	TK-5232K	K	2.6K	NA/LA		
ALK-TK5232C	TK-5232C	C	2.2K	NA/LA		
ALK-TK5232M	TK-5232M	M	2.2K	NA/LA		
ALK-TK5232Y	TK-5232Y	Y	2.2K	NA/LA		
ALK-TK5233K	TK-5233K	K	2.6K	CHN		
ALK-TK5233C	TK-5233C	C	2.2K	CHN		
ALK-TK5233M	TK-5233M	M	2.2K	CHN		
ALK-TK5233Y	TK-5233Y	Y	2.2K	CHN		
ALK-TK5234K	TK-5234K	K	2.6K	AU/India	Kyocera Ecosys M5521CDN/M5521CDW/P5021CDN/P5021CDW	
ALK-TK5234C	TK-5234C	C	2.2K	AU/India		
ALK-TK5234M	TK-5234M	M	2.2K	AU/India		
ALK-TK5234Y	TK-5234Y	Y	2.2K	AU/India		
ALK-TK5234KK	TK-5234KK	K	2.6K	KOR		
ALK-TK5234KC	TK-5234KC	C	2.2K	KOR		
ALK-TK5234KM	TK-5234KM	M	2.2K	KOR		
ALK-TK5234KY	TK-5234KY	Y	2.2K	KOR		
ALK-TK5236K	TK-5236K	K	2.6K	TW		Kyocera Ecosys M5520cdn/M5520cdw/P5020cdn/P5020cdw
ALK-TK5236C	TK-5236C	C	2.2K	TW		
ALK-TK5236M	TK-5236M	M	2.2K	TW		
ALK-TK5236Y	TK-5236Y	Y	2.2K	TW		
ALK-TK5240K	TK-5240K	K	4K	EUR	Kyocera ECOSYS M5526cdw/P5026cdw/P5026cdn	
ALK-TK5240C	TK-5240C	C	3K	EUR		
ALK-TK5240M	TK-5240M	M	3K	EUR		
ALK-TK5240Y	TK-5240Y	Y	3K	EUR		
ALK-TK5241K	TK-5241K	K	4K	JP	Kyocera ECOSYS M5526cdw/P5026cdw	
ALK-TK5241C	TK-5241C	C	3K	JP		
ALK-TK5241M	TK-5241M	M	3K	JP		
ALK-TK5241Y	TK-5241Y	Y	3K	JP		
ALK-TK5242K	TK-5242K	K	3K	NA/LA		
ALK-TK5242C	TK-5242C	C	3K	NA/LA		
ALK-TK5242M	TK-5242M	M	3K	NA/LA		
ALK-TK5242Y	TK-5242Y	Y	3K	NA/LA		
ALK-TK5244K	TK-5244K	K	4K	AU/India	Kyocera M5526CDN/M5526CDW/P5026CDN/P5026CDW	
ALK-TK5244C	TK-5244C	C	3K	AU/India		
ALK-TK5244M	TK-5244M	M	3K	AU/India		
ALK-TK5244Y	TK-5244Y	Y	3K	AU/India		
ALK-TK5244KK	TK-5244KK	K	4K	KOR		
ALK-TK5244KC	TK-5244KC	C	3K	KOR		
ALK-TK5244KM	TK-5244KM	M	3K	KOR		
ALK-TK5244KY	TK-5244KY	Y	3K	KOR		
ALK-TK5246K	TK-5246K	K	4K	TW	Kyocera Ecosys M5525cdn/P5025cdn	
ALK-TK5246C	TK-5246C	C	3K	TW		
ALK-TK5246M	TK-5246M	M	3K	TW		
ALK-TK5246Y	TK-5246Y	Y	3K	TW		
ALU-PK5014K	PK-5014K	K	2.6K	EUR	Utax P-C2155w MFP	
ALU-PK5014C	PK-5014C	C	2.2K	EUR		
ALU-PK5014M	PK-5014M	M	2.2K	EUR		
ALU-PK5014Y	PK-5014Y	Y	2.2K	EUR		

		UTAX	ALU-PK5015K	PK-5015K	K	4K	EUR	Utax P-C2650DW/C2655w	
			ALU-PK5015C	PK-5015C	C	3K	EUR		
			ALU-PK5015M	PK-5015M	M	3K	EUR		
			ALU-PK5015Y	PK-5015Y	Y	3K	EUR		
			ALU-PK5016K	PK-5016K	K	1.2K	EUR		Utax P-C2155w MFP
			ALU-PK5016C	PK-5016C	C	1.2K	EUR		
			ALU-PK5016M	PK-5016M	M	1.2K	EUR		
			ALU-PK5016Y	PK-5016Y	Y	1.2K	EUR		
B59	 	Kyocera	ALK-TK6115	TK-6115	K	15K	EUR	Kyocera ECOSYS M4132idn/M4125idn	
			ALK-TK6117	TK-6117	K	15K	NA		
			ALK-TK6128	TK-6128	K	20K		Kyocera ECOSYS M4132idn	
			ALK-TK8115K	TK-8115K	K	12K	EUR		
			ALK-TK8115C	TK-8115C	C	6K			
			ALK-TK8115M	TK-8115M	M	6K			
			ALK-TK8115Y	TK-8115Y	Y	6K			
			ALK-TK8117K	TK-8117K	K	12K	NA		
			ALK-TK8117C	TK-8117C	C	6K			
			ALK-TK8117M	TK-8117M	M	6K			
ALK-TK8117Y	TK-8117Y	Y	6K						
B63	 	Kyocera	ALK-TK5270K	TK-5270K	K	8K	EUR	Kyocera ECOSYS M6230cidn/P6230cdn/M6630cidn	
			ALK-TK5270C	TK-5270C	C	6K	EUR		
			ALK-TK5270M	TK-5270M	M	6K	EUR		
			ALK-TK5270Y	TK-5270Y	Y	6K	EUR		
			ALK-TK5280K	TK-5280K	K	13K	EUR		
			ALK-TK5280C	TK-5280C	C	11K	EUR		
			ALK-TK5280M	TK-5280M	M	11K	EUR		
			ALK-TK5280Y	TK-5280Y	Y	11K	EUR		
			ALK-TK5290K	TK-5290K	K	17K	EUR		Kyocera ECOSYS P7240cdn
			ALK-TK5290C	TK-5290C	C	13K	EUR		
			ALK-TK5290M	TK-5290M	M	13K	EUR		
			ALK-TK5290Y	TK-5290Y	Y	13K	EUR		
			B44			ALR-C2503HK-AU	MP-C2503/841932	BK	15K
ALR-C2503HC-AU	MP-C2503H/841935	C				9.5K	AU		
ALR-C2503HM-AU	MP-C2503H/841934	M				9.5K	AU		
ALR-C2503HY-AU	MP-C2503H/841933	Y				9.5K	AU		
ALR-C2503HK-EUR	MP-C2503/841925	BK				15K	EUR		
ALR-C2503HC-EUR	MP-C2503H/841928	C				9.5K	EUR		
ALR-C2503HM-EUR	MP-C2503H/841927	M				9.5K	EUR		
ALR-C2503HY-EUR	MP-C2503H/841926	Y				9.5K	EUR		
ALR-C2503HK-NA	MP-C2503/841918	BK				15K	NA		
ALR-C2503HC-NA	MP-C2503H/841921	C				9.5K	NA		
ALR-C2503HM-NA	MP-C2503H/841920	M				9.5K	NA		
ALR-C2503HY-NA	MP-C2503H/841919	Y				9.5K	NA		
ALR-C2503HK-CHN	MP-C2503/841946	BK				15K	CHN		
ALR-C2503C-JP	MP-C2503/600284	C				5.5K	JP		
ALR-C2503M-JP	MP-C2503/600283	M				5.5K	JP		
ALR-C2503Y-JP	MP-C2503/600282	Y				5.5K	JP		
ALR-C2503C-NA	MP-C2503/841924	C				5.5K	NA		
ALR-C2503M-NA	MP-C2503/841923	M				5.5K	NA		
ALR-C2503Y-NA	MP-C2503/841922	Y	5.5K	NA					



ALR-C3503K-AU	MP-C3503/841829	BK	29.5K	AU	Ricoh MP C2003/MP C2503/MP C2004/MP C2504
ALR-C3503C-AU	MP-C3503/841832	C	18K	AU	
ALR-C3503M-AU	MP-C3503/841831	M	18K	AU	
ALR-C3503Y-AU	MP-C3503/841830	Y	18K	AU	
ALR-C3503K-CHN	MP-C3503/841841	BK	29.5K	CHN	
ALR-C3503C-CHN	MP-C3503/841844	C	18K	CHN	
ALR-C3503M-CHN	MP-C3503/841843	M	18K	CHN	
ALR-C3503Y-CHN	MP-C3503/841842	Y	18K	CHN	
ALR-C3503K-EUR	MP-C3503/841817	BK	29.5K	EUR	
ALR-C3503C-EUR	MP-C3503/841820	C	18K	EUR	
ALR-C3503M-EUR	MP-C3503/841819	M	18K	EUR	
ALR-C3503Y-EUR	MP-C3503/841818	Y	18K	EUR	
ALR-C3503K-JP	MP-C3503/600249	BK	29.5K	JP	
ALR-C3503C-JP	MP-C3503/600252	C	18K	JP	
ALR-C3503M-JP	MP-C3503/600251	M	18K	JP	
ALR-C3503Y-JP	MP-C3503/600250	Y	18K	JP	
ALR-C3503K-NA	MP-C3503/841813	BK	29.5K	NA	
ALR-C3503C-NA	MP-C3503/841816	C	18K	NA	
ALR-C3503M-NA	MP-C3503/841815	M	18K	NA	
ALR-C3503Y-NA	MP-C3503/841814	Y	18K	NA	
ALR-C6003K-AU	MP-C6003/841865	BK	33K	AU	
ALR-C6003C-AU	MP-C6003/841868	C	22.5K	AU	
ALR-C6003M-AU	MP-C6003/841867	M	22.5K	AU	
ALR-C6003Y-AU	MP-C6003/841866	Y	22.5K	AU	
ALR-C6003K-CHN	MP-C6003/841877	BK	33K	CHN	
ALR-C6003C-CHN	MP-C6003/841880	C	22.5K	CHN	
ALR-C6003M-CHN	MP-C6003/841879	M	22.5K	CHN	
ALR-C6003Y-CHN	MP-C6003/841878	Y	22.5K	CHN	
ALR-C6003K-EUR	MP-C6003/841853	BK	33K	EUR	
ALR-C6003C-EUR	MP-C6003/841856	C	22.5K	EUR	
ALR-C6003M-EUR	MP-C6003/841855	M	22.5K	EUR	
ALR-C6003Y-EUR	MP-C6003/841854	Y	22.5K	EUR	
ALR-C6003K-NA	MP-C6003/841849	BK	33K	NA	
ALR-C6003C-NA	MP-C6003/841852	C	22.5K	NA	
ALR-C6003M-NA	MP-C6003/841851	M	22.5K	NA	
ALR-C6003Y-NA	MP-C6003/841850	Y	22.5K	NA	
ALR-C6003K-JP	MP-C6003/600244	BK	33K	JP	
ALR-C6003C-JP	MP-C6003/600245	C	22.5K	JP	
ALR-C6003M-JP	MP-C6003/600246	M	22.5K	JP	
ALR-C6003Y-JP	MP-C6003/600247	Y	22.5K	JP	
ALR-C406K-CHN	MP-C406/842111	BK	17K	CHN	
ALR-C406C-CHN	MP-C406/842112	C	6K	CHN	
ALR-C406M-CHN	MP-C406/842113	M	6K	CHN	
ALR-C406Y-CHN	MP-C406/842114	Y	6K	CHN	
ALR-C406K-EUR	MP-C406/842095	BK	17K	EUR	
ALR-C406C-EUR	MP-C406/842096	C	6K	EUR	
ALR-C406M-EUR	MP-C406/842097	M	6K	EUR	
ALR-C406Y-EUR	MP-C406/842098	Y	6K	EUR	
ALR-C406K-NA	MP-C406/842091	BK	17K	NA	
ALR-C406C-NA	MP-C406/842092	C	6K	NA	
					Ricoh MP C5503/MP C4503/MP C6003/MP C4504/MP C5504/MP C6004
					Ricoh MP C306/MP C406/MP C307/MP C407



Ricoh

ALR-C406M-NA	MP-C406/842093	M	6K	NA
ALR-C406Y-NA	MP-C406/842094	Y	6K	NA
ALR-C406K-JP	MP-C406/600342	BK	17K	JP
ALR-C406C-JP	MP-C406/600343	C	6K	JP
ALR-C406M-JP	MP-C406/600344	M	6K	JP
ALR-C406Y-JP	MP-C406/600345	Y	6K	JP
ALR-C407K-NA	MP-C407/842207	BK	17.5K	WW
ALR-C407C-NA	MP-C407/842208	C	8K	WW
ALR-C407M-NA	MP-C407/842209	M	8K	WW
ALR-C407Y-NA	MP-C407/842210	Y	8K	WW
ALR-C840HK-JP	SP-C840H/600637	BK	25K	JP
ALR-C840HC-JP	SP-C840H/600634	C	20K	JP
ALR-C840HM-JP	SP-C840H/600635	M	20K	JP
ALR-C840HY-JP	SP-C840H/600636	Y	20K	JP
ALR-C840AK-JP	SP-C840A/821255	BK	43K	WW(ex.JP)
ALR-C840AC-JP	SP-C840A/821258	C	34K	WW(ex.JP)
ALR-C840AM-JP	SP-C840A/821257	M	34K	WW(ex.JP)
ALR-C840AY-JP	SP-C840A/821256	Y	34K	WW(ex.JP)
ALR-C840K-JP	SP-C840/600633	BK	12K	JP
ALR-C840C-JP	SP-C840/600630	C	12K	JP
ALR-C840M-JP	SP-C840/600631	M	12K	JP
ALR-C840Y-JP	SP-C840/600632	Y	12K	JP
ALR-C830HK-NA	SP-C830H/821181	BK	23.5K	WW(ex.JP)
ALR-C830HC-NA	SP-C830H/821184	C	27K	WW(ex.JP)
ALR-C830HM-NA	SP-C830H/821183	M	27K	WW(ex.JP)
ALR-C830HY-NA	SP-C830H/821182	Y	27K	WW(ex.JP)
ALR-C830HK-JP	SP-C830H/600514	BK	25K	JP
ALR-C830HC-JP	SP-C830H/600517	C	20K	JP
ALR-C830HM-JP	SP-C830H/600516	M	20K	JP
ALR-C830HY-JP	SP-C830H/600515	Y	20K	JP
ALR-C830K-JP	SP-C830/600518	BK	12K	JP
ALR-C830C-JP	SP-C830/600521	C	12K	JP
ALR-C830M-JP	SP-C830/600520	M	12K	JP
ALR-C830Y-JP	SP-C830/600519	Y	12K	JP
ALR-C830K-NA	SP-C830/821149	BK	12K	WW(ex.JP)
ALR-C830C-NA	SP-C830/821152	C	12K	WW(ex.JP)
ALR-C830M-NA	SP-C830/821151	M	12K	WW(ex.JP)
ALR-C830Y-NA	SP-C830/821150	Y	12K	WW(ex.JP)
ALR-C305HK-CHN	MP-C305H/841633	BK	12K	CHN
ALR-C305HC-CHN	MP-C305H/841625	C	4K	CHN
ALR-C305HM-CHN	MP-C305H/841626	M	4K	CHN
ALR-C305HY-CHN	MP-C305H/841627	Y	4K	CHN
ALR-C305HK-EUR	MP-C305H/842079	BK	12K	EUR
ALR-C305HC-EUR	MP-C305H/842082	C	4K	EUR
ALR-C305HM-EUR	MP-C305H/842081	M	4K	EUR
ALR-C305HY-EUR	MP-C305H/841627	Y	4K	EUR
ALR-C305HK-NA	MP-C305H/842119	BK	12K	NA
ALR-C305HC-NA	MP-C305H/841122	C	4K	NA
ALR-C305HM-NA	MP-C305H/841121	M	4K	NA
ALR-C305HY-NA	MP-C305H/841120	Y	4K	NA

Ricoh MP C407SPF

Ricoh SP C841/C841M/C840/C840M

Ricoh SP C840DN/SP C842DN





Ricoh SP C841/C841M/C840/C840M

Ricoh IPSiO SP C831/831M/C830/830M

Ricoh Aficio MP C305spf

ALR-C305HK-JP	MP-C305H/600273	BK	12K	JP	
ALR-C305HC-JP	MP-C305H/600274	C	4K	JP	
ALR-C305HM-JP	MP-C305H/600275	M	4K	JP	
ALR-C305HY-JP	MP-C305H/600276	Y	4K	JP	
ALR-1803K-JP	MP-C1803/600286	BK	3K	JP	
ALR-1803C-JP	MP-C1803/600287	C	1.4K	JP	Ricoh MP C1803
ALR-1803M-JP	MP-C1803/600288	M	1.4K	JP	
ALR-1803Y-JP	MP-C1803/600289	Y	1.4K	JP	
ALR-C3502K-CHN	MP-C3502/841675	BK	28K	CHN	
ALR-C3502C-CHN	MP-C3502/841678	C	18K	CHN	
ALR-C3502M-CHN	MP-C3502/841677	M	18K	CHN	
ALR-C3502Y-CHN	MP-C3502/841676	Y	18K	CHN	
ALR-C3502K-NA	MP-C3502/841735	BK	28K	NA	
ALR-C3502C-NA	MP-C3502/841738	C	18K	NA	
ALR-C3502M-NA	MP-C3502/841737	M	18K	NA	
ALR-C3502Y-NA	MP-C3502/841736	Y	18K	NA	
ALR-C5502K-CHN	MP-C5502/841707	BK	31K	CHN	
ALR-C5502C-CHN	MP-C5502/841710	C	22.5K	CHN	Ricoh MPC3002/MPC3502
ALR-C5502M-CHN	MP-C5502/841709	M	22.5K	CHN	
ALR-C5502Y-CHN	MP-C5502/841708	Y	22.5K	CHN	
ALR-C5502K-EUR	MP-C5502/842020	BK	31K	EUR	
ALR-C5502C-EUR	MP-C5502/842023	C	22.5K	EUR	
ALR-C5502M-EUR	MP-C5502/842022	M	22.5K	EUR	
ALR-C5502Y-EUR	MP-C5502/842021	Y	22.5K	EUR	
ALR-C5502K-NA	MP-C5502/841751	BK	31K	NA	
ALR-C5502C-NA	MP-C5502/841754	C	22.5K	NA	
ALR-C5502M-NA	MP-C5502/841753	M	22.5K	NA	
ALR-C5502Y-NA	MP-C5502/841752	Y	22.5K	NA	
ALR-C8003K-NA	MP-C8003/842196	BK	47K	NA	
ALR-C8003C-NA	MP-C8003/842199	C	26K	NA	
ALR-C8003M-NA	MP-C8003/842198	M	26K	NA	
ALR-C8003Y-NA	MP-C8003/842197	Y	26K	NA	
ALR-C8003K-JP	MP-C8003/600375	BK	47K	JP	Ricoh MP C8003/C6503
ALR-C8003C-JP	MP-C8003/600377	C	26K	JP	
ALR-C8003M-JP	MP-C8003/600378	M	26K	JP	
ALR-C8003Y-JP	MP-C8003/600376	Y	26K	JP	
ALR-C5200K-NA	C5200/828422	BK	33K	NA	
ALR-C5200C-NA	C5200/828425	C	24K	NA	
ALR-C5200M-NA	C5200/828424	M	24K	NA	
ALR-C5200Y-NA	C5200/828423	Y	24K	NA	
ALR-C5200K-JP	C5200/600379	BK	33K	JP	Ricoh Pro C5200S/Pro C5210S
ALR-C5200C-JP	C5200/600382	C	24K	JP	
ALR-C5200M-JP	C5200/600381	M	24K	JP	
ALR-C5200Y-JP	C5200/600380	Y	24K	JP	
UNKNOWN	RST-Ricoh-3502				Ricoh Aficio MP C305spf/C306/C406/C307/C407spf/C1803/C2003/C2503/C2004/C2 504/C3002/C3003/C3502/C3503/C3004/C3504/C4502/C4503/C4504/ C5502/C5503/C5504/C6003/C6004/C6502sp/C6503/C8002sp/C8003 /SP C830/830M/C831/831M/C841/a1/C841M/a1/C840/a1/C840M/a1/C840 DN/C842DN/Pro C5100S/C5110S/C5200S/C5210S

**Note:** The chip pictures shown above are not exactly pictures of OEM's chips.  
All other brand or product names mentioned are intended to show compatibility only.

PCB Code	Jig	Brand	Apex Product Code	OEM Product Code	For Use with
<b>RST-EPSON-1</b> (Epson B OEM inkjet chips) 		Epson	T026/T027/T028/T029	T026/T027/T028/T029	Epson® Stylus Photo 810/820/830/830U Epson® Stylus Photo 925/935 Epson® Stylus Photo C60/C61/CX3100
			T0321/T0322/T0323/T0324	T0321/T0322/T0323/T0324	Epson® Stylus C70/C80/C80N/C80WN/C82/C82N/C82WN Epson® Stylus CX5100/CX5200/CX5300/CX5400
			T0331/T0331/T0332/T0333/T0334/T0335/T0336	T0331/T0331/T0332/T0333/T0334/T0335/T0336	Epson® Stylus Photo 950/960
			T0341/T0342/T0343/T0344/T0345/T0346/T0347/T0348	T0341/T0342/T0343/T0344/T0345/T0346/T0347/T0348	Epson® Stylus Photo 2100/2200
			T036/T037	T036/T037	Epson® Stylus C42/C44/C46
			T038/T039	T038/T039	Epson® Stylus C41/C43/C43U/C45 Epson® Stylus CX1500/CX1500v
			T040/T041	T040/T041	Epson® Stylus CX3200/C62
			T0321/T0422/T0423/T0424	T0321/T0422/T0423/T0424	Epson® Stylus CX5100/CX5200/CX5300/CX5400 Epson® Stylus C82/C82N/C82WN
			T0431/T0442/T0443/T0444	T0431/T0442/T0443/T0444	Epson® Stylus C84/C84N/C84WN Epson® Stylus CX6400/CX6600
			T0441/T0442/T0443/T0444	T0441/T0442/T0443/T0444	Epson® Stylus C64/C66/C84/C84N/C84WN/C86 Epson® Stylus CX3600/CX3650 Epson® Stylus CX4600/CX6400/CX6600
			T0441/T0452/T0453/T0454	T0441/T0452/T0453/T0454	Epson® Stylus C64/C66/C84/C86 Epson® Stylus CX6600/CX3600/CX3650
			T0461/T0472/T0473/T0474	T0461/T0472/T0473/T0474	Epson® Stylus C63/C65/C83/C85 Epson® Stylus CX3500/CX4500/CX6300/CX6500
			T0481/T0482/T0483/T0484/T0485/T0486	T0481/T0482/T0483/T0484/T0485/T0486	Epson® Stylus Photo R200/R220/R300/R300M/R320/R340 Epson® Stylus Photo RX500/RX600/RX620
			T0491/T0492/T0493/T0494/0495/T0496	T0491/T0492/T0493/T0494/0495/T0496	Epson® Stylus Photo R210/R230/R310/R350 Epson® Stylus Photo RX510/RX630
			T0540/T0541/T0542/T0543/0544/T0547/T0548/T0549	T0540/T0541/T0542/T0543/0544/T0547/T0548/T0549	Epson® Stylus Photo R800/R1800
			T0551/T0552/T0553/T0554	T0551/T0552/T0553/T0554	Epson® Stylus Photo R240/RX420/RX425/RX520
			T5591/T54592/T5593/T5594/T5595/T5596	T5591/T54592/T5593/T5594/T5595/T5596	Epson® Stylus Photo RX700
			T0561/T0562/T0563/T0564	T0561/T0562/T0563/T0564	Epson® Stylus Photo R250/RX430/RX530
			T057/T058	T057/T058	EPSON® ME 1 EPSON® ME 100 EPSON® ME1+
			T0557	T0557	EPSON® PictureMate /PictureMate 500
			T0573	T0573	Epson® PictureMate 100 Epson® PictureMate 100 Mobile Phone Edition
			T0591/T0592/T0593/T0594/T0595/T0596/T0597/T0598/T0599	T0591/T0592/T0593/T0594/T0595/T0596/T0597/T0598/T0599	Epson® Stylus Photo R2400
			T0601/T0602/T0603/T0604	T0601/T0602/T0603/T0604	Epson® Stylus C88 Epson® Stylus CX3800/CX3810/CX4200/CX4800/CX5800F/CX7800
			T0611H/T0611/T0612/T0613/T0614	T0611H/T0611/T0612/T0613/T0614	Epson® Stylus D88/D68 series Epson® Stylus DX3800/DX3850 Epson® Stylus DX4800/DX4850
			T0631/T0632/T0633/T0634	T0631/T0632/T0633/T0634	Epson® Stylus C67/C87 Epson® Stylus CX3700/CX4100/CX4700
			T066/T067	T066/T067	Epson® Stylus C48
			T0841/T0842/T0843/T0844	T0841/T0842/T0843/T0844	Epson® Stylus Photo 20
			<b>RST-EPSON-1</b> (Epson C OEM inkjet chips) 		Epson
T6041/T6042/T6043/T6044/T6045/T6046/T6047/T6049/T6128	T6041/T6042/T6043/T6044/T6045/T6046/T6047/T6049/T6128	Epson® Stylus PRO 9880C/7880C			
T6051/T6052/T6053/T6054/T6055/T6056/T6057/T6059	T6051/T6052/T6053/T6054/T6055/T6056/T6057/T6059	Epson® Stylus Pro 4880 ColorBurst Epson® Stylus Pro 4880 Portrait Edition (USA)			
T499/T500/T501/T502/T503/T504	T499/T500/T501/T502/T503/T504	Epson® Stylus Pro 10000/10600(PHOTOGRA)			



T511/T512/T513/T514/T515/T516	T511/T512/T513/T514/T515/T516	Epson® Stylus Pro 10000CF/10600(ARCHIVAL)
T5431/T5432/T5433/T5434/T5435/T5436/T5437	T5431/T5432/T5433/T5434/T5435/T5436/T5437	Epson® Stylus Pro 4000/7600/9600(ULTRACHROME)
T5438	T5438	Epson® Stylus Pro 4000/4400/4800/7600/9600(ULTRACHROME)
T5441/T5442/T5443/T5444/T5445/T5446/T5447	T5441/T5442/T5443/T5444/T5445/T5446/T5447	Epson® Stylus Pro 4000/9600(ULTRACHROME)

**RST-EPSON-1**  
(Epson C OEM inkjet chips)



T5448	T5448	Epson® Stylus Pro 4000/4400/4800/9600(ULTRACHROME)
T5451/T5452/T5453/T5454/T5455/T5456	T5451/T5452/T5453/T5454/T5455/T5456	Epson® Stylus Pro 7600/9600(ULTRACHROME)
T5491/T5492/T5493/T5494/T5495/T5496/T5497/T5498	T5491/T5492/T5493/T5494/T5495/T5496/T5497/T5498	Epson® Stylus Pro 10600
T5621/T5622/T5623/T5624/T5625/T5626/T5627/T5629	T5621/T5622/T5623/T5624/T5625/T5626/T5627/T5629	Epson® Stylus Pro 7800/9800
T5631/T5632/T5633/T5634/T5635/T5636/T5637/T5639	T5631/T5632/T5633/T5634/T5635/T5636/T5637/T5639	Epson® Stylus Pro 7800/9800
T5641/T5642/T5643/T5644/T5645/T5646/T5647/T5649	T5641/T5642/T5643/T5644/T5645/T5646/T5647/T5649	Epson® Stylus Pro 4800
T5651/T5652/T5653/T5654/T5655/T5656/T5657/T5659	T5651/T5652/T5653/T5654/T5655/T5656/T5657/T5659	Epson® Stylus Pro 4800
T5662/T5663/T5664/T5668/T5678	T5662/T5663/T5664/T5668/T5678	Epson® Stylus Pro 7400/7800/9400/9800
T5672/T5673/T5674	T5672/T5673/T5674	Epson® Stylus Pro 7400/9400

Epson

**RST-EPSON-2**  
(Epson 9-pin inkjet chips)



T0682/T0683/T0684	T0682/T0683/T0684	Epson® WorkForce 40/500/600/610/615 Epson® WorkForce NX510/515
T1002/T1003/T1004	T1002/T1003/T1004	Epson® Stylus SX600FW/SX510W
T1232/T1233/T1234	T1232/T1233/T1234	Epson® Stylus ME OFFICE 80W/700FW
T1191/T1191/T1092/T1093/T1094	T1191/T1191/T1092/T1093/T1094	Epson® ME OFFICE 70/1100
T1191/T1191/T1232/T1233/T1234	T1191/T1191/T1232/T1233/T1234	Epson® ME OFFICE 1100
T1091/T1091/T1092/T1093/T1094	T1091/T1091/T1092/T1093/T1094	Epson® ME 30/ME360/ME300/ Epson® ME OFFICE 70 Epson® ME OFFICE 360/80W/700FW/600F/510/520
T1091/T1092/T1093/T1094	T1091/T1092/T1093/T1094	Epson® ME 30/ME360/ME300/ Epson® ME OFFICE 70 Epson® ME OFFICE 360/80W/700FW/600F/510/520
T0691/T0692/T0693/T0694	T0691/T0692/T0693/T0694	Epson® Stylus CX7400/CX7000F/CX6000/CX5000 Epson® Stylus CX8400/CX9400FAX/CX7450/CX9475FAX Epson® Stylus NX100/NX115/NX200/NX215/NX400/NX300/NX415/NX105/NX110/NX305/NX510/NX515 Epson® Workforce 30/500/600/610/615/40
T0691/T0691/T0692/T0693/T0694	T0691/T0691/T0692/T0693/T0694	Epson® Stylus WorkForce 30/310/315/1100
T0681/T0682/T0683/T0684	T0681/T0682/T0683/T0684	Epson® WorkForce 40/500/600/610/615 Epson® NX510/515/CX5000/CX6000/CX7000F/CX8400/CX9400/CX9475
T0711/T0712/T0713/T0714	T0711/T0712/T0713/T0714	Epson® Stylus D78/D92/DX7000F/DX5000/DX4050/4000/4400/4450/DX5050/DX6000 Epson® Stylus DX6050/DX7400/DX7450/DX8400/DX8450/DX9400/DX9400F Epson® Stylus S20/S21 Epson® Stylus SX100/SX110/SX200/SX209/SX210/SX400/SX510W Epson® Stylus SX410/SX610FW/SX600FW/SX205/SX215/SX105/SX405 Epson® Stylus BX310FN/BX300F/BX3450F/BX600FW/BX610FW/B40W
T0711H/T0712/T0713/T0714	T0711H/T0712/T0713/T0714	Epson® Stylus SX410/SX510W
T0711/T0711/T0712/T0713/T0714	T0711/T0711/T0712/T0713/T0714	Epson® D120
T0711H/T0711H/T0712/T0713/T0714	T0711H/T0711H/T0712/T0713/T0714	Epson® D120
T0731/T0732/T0733/T0734	T0731/T0732/T0733/T0734	Epson® Stylus C79/C90/C92/C110 Epson® Stylus CX3900/CX4900/CX4905/CX5600/CX5900F/CX6900F Epson® Stylus CX7310/8300/CX7300 Epson® Stylus CX5500/CX5501/CX5505/CX5510
T0731H/T0732/T0733/T0734	T0731H/T0732/T0733/T0734	Epson® Stylus C110 Epson® Stylus CX9300F
T0881/T0882/T0883/T0884	T0881/T0882/T0883/T0884	Epson® Stylus CX4400/CX4450/CX7400/CX7450/N11 Epson® Stylus NX200/NX400/NX100/NX115/NX105/NX110/NX215/NX300/NX305/NX415/NX510
T0891/T0892/T0893/T0894	T0891/T0892/T0893/T0894	Epson® Stylus S20/S21 Epson® Stylus SX100/SX105/SX115/SX110/SX210/SX215/SX218/SX415 Epson® Stylus SX200/SX205/SX400/SX405/SX410 Epson® Stylus SX510W
T0911/T0912/T0913/T0914	T0911/T0912/T0913/T0914	Epson® Stylus C90 Epson® Stylus CX5500/CX5501/CX5510/CX5505

Epson II



**RST-EPSON-2**  
(Epson 9-pin inkjet chips)



Epson II

T0901/T0732/T0733/T0734	T0901/T0732/T0733/T0734	Epson® Stylus C92/C90/CX5600/T20/T21/TX110
T0921/T0922/T0923/T0924	T0921/T0922/T0923/T0924	Epson® Stylus C91/CX4300
T0681/T0681/T0692/T0693/T0694	T0681/T0681/T0692/T0693/T0694	Epson® Stylus C120
T0771/T0772/T0773/T0774/T0775/T0776	T0771/T0772/T0773/T0774/T0775/T0776	Epson® Stylus Photo R260/R380/R280 Epson® Stylus Photo RX580/RX680/RX595 Epson® Artisan 50
T0781/T0782/T0783/T0784/T0785/T0786	T0781/T0782/T0783/T0784/T0785/T0786	Epson® Stylus Photo R260/R380/R280 Epson® Stylus Photo RX580/RX680/RX595 Epson® Stylus Photo Artisan50
T0791/T0792/T0793/T0794/T0795/T0796	T0791/T0792/T0793/T0794/T0795/T0796	Epson® Stylus Photo 1400/PX700W/PX800FW/P50/PX830FWD Epson® Artisan 1430
T0801/T0802/T0803/T0804/T0805/T0806	T0801/T0802/T0803/T0804/T0805/T0806	Epson® Stylus Photo R265/R360/R285 Epson® Stylus Photo RX585/RX685/RX560 Epson® Stylus Photo P50/PX820FWD/PX830FWD Epson® Stylus PX700W/PX710W/PX800FW/PX810/PX650/PX50/PX660/PX720WD/PX730WD
T0811/T0812/T0813/T0814/T0815/T0816	T0811/T0812/T0813/T0814/T0815/T0816	Epson® Stylus Photo R390/RX590/R270/RX690/RX610/RX615/R290/R295 Epson® Stylus photo 1410
T0821/T0822/T0823/T0824/T0825/T0826	T0821/T0822/T0823/T0824/T0825/T0826	Epson® Stylus R390/R270/R290/R295 Epson® Stylus RX590/RX615/RX610/RX690
T0851/T0852/T0853/T0854/T0855/T0856	T0851/T0852/T0853/T0854/T0855/T0856	Epson® Stylus Photo 1390
T0870/T0871/T0872/T0873/T0874/T0877/T0878/T0879	T0870/T0871/T0872/T0873/T0874/T0877/T0878/T0879	Epson® Stylus Photo R1900
ICBK50/ICC50/ICM50/ICY50/ICLC50/ICLM50	ICBK50/ICC50/ICM50/ICY50/ICLC50/ICLM50	Epson® PM-G850 Epson® PM-G4500 Epson® PM-T960 Epson® PM-A940/A920 Epson® PM-A840S/D870 Epson® PM-A840/A820 Epson® PM-G860 Epson® EP-301/302 Epson® EP-774A Epson® EP-4004 Epson® EP-901F/901A/902A/903A/903F/904F/904A/803AW/705A Epson® EP-801A/802A/803A/803AW/702A/703A/804A/804AW/804AR/704A
ICBK51/ICC51/ICM51/ICY51/ICLC51/ICLM51	ICBK51/ICC51/ICM51/ICY51/ICLC51/ICLM51	Epson® EP- 703A/704A/705A/774A/803A/803AW/804A/804AR/804AW/903A/903F/904A/904F
ICBK53/ICC53/ICM53/ICY53/CMB53/ICR53/ICOR53/ICGL53	ICBK53/ICC53/ICM53/ICY53/CMB53/ICR53/ICOR53/ICGL53	Epson® PX-G5300
ICBK46/ICC46/ICM46/ICY46	ICBK46/ICC46/ICM46/ICY46	Epson® PX-A720/A740 Epson® FA700 Epson® A620/A640 Epson® PX-V780 Epson® PX-401A/402A Epson® PX-501A Epson® PX-101
ICBK56/ICC46/ICM46/ICY46	ICBK56/ICC46/ICM46/ICY46	Epson® PX-201/502A/601F/602F
ICBK59/ICBK59/ICC59/ICM59/ICY59	ICBK59/ICBK59/ICC59/ICM59/ICY59	Epson® PX-1001
T0731N/T0732N/T0733N/T0734N	T0731N/T0732N/T0733N/T0734N	Epson® Stylus T10/T11/T20/T21/T40W/T13/TX220/T20E/TX213 Epson® Stylus TX100/TX101/TX200/TX209/TX110/TX210/TX300F/TX121 Epson® Stylus TX400/TX409/TX550W/TX610/TX600FW/TX410 Epson® Stylus C79/CX8300/CX5500
T0731HN/T0732N/T0733N/T0734N	T0731HN/T0732N/T0733N/T0734N	Epson® Stylus T40W/TX550W/TX410/TX200/TX400 Epson® Stylus TX610/TX600FW
T0851N/T0852N/T0853N/T0854N/T0855N/T0856N	T0851N/T0852N/T0853N/T0854N/T0855N/T0856N	Epson® Stylus T60
T0901N/T0732N/T0733N/T0734N	T0901N/T0732N/T0733N/T0734N	Epson® Stylus T20/TX100
T0911N/T0912N/T0913N/T0914N	T0911N/T0912N/T0913N/T0914N	Epson® Stylus TX101/T21/TX110/TX210/TX111/TX610/TX121 Epson® Stylus C91
T0921N/T0922N/T0923N/T0924N	T0921N/T0922N/T0923N/T0924N	Epson® Stylus T26/T27/TX117/TX119/TX106/TX109 Epson® Stylus CX4300/C91
T0981/T0982/T0983/T0984/T0985/T0986	T0981/T0982/T0983/T0984/T0985/T0986	Epson® Artisan 600/700/800/710/810/725/835/837/730
T0981/T0992/T0993/T0994/T0995/T0996	T0981/T0992/T0993/T0994/T0995/T0996	
T0811N/T0812N/T0813N/T0814N/T0815N/T0816N	T0811N/T0812N/T0813N/T0814N/T0815N/T0816N	Epson® Stylus Photo TX700/TX800/T50/TX710W/TX650/TX810FW/TX820FWD Epson® Stylus RX615/R270/R290 Epson® Artisan 1430/837




T0821N/T0822N/T0823N/T0824N/T0825N/T0826N
T1171/T0732N/T0733N/T0734N
T1031/T1032/T1033/T1034
T0731HN/T0731HN/T0732N/T0733N/T0734N
T1151/T1151/T0732N/T0733N/T 0734N
T1151/T1151/T1032/T1033/T1034
T0731N/T0731N/T0732N/T0733N/T0734N
T0731HN/T0731HN/T1032/T1033/T1034
T0971
T1001
T1231/T1232/T1233/T1234
ICBK56

T0821N/T0822N/T0823N/T0824N/T0825N/T0826N
T1171/T0732N/T0733N/T0734N
T1031/T1032/T1033/T1034
T0731HN/T0731HN/T0732N/T0733N/T0734N
T1151/T1151/T0732N/T0733N/T 0734N
T1151/T1151/T1032/T1033/T1034
T0731N/T0731N/T0732N/T0733N/T0734N
T0731HN/T0731HN/T1032/T1033/T1034
T0971
T1001
T1231/T1232/T1233/T1234
ICBK56

Epson® Stylus Photo TX700/TX800/TX710W/TX650/TX810FW/TX820FWD Epson® Stylus Photo RX615/R270/R290 Epson® Stylus Photo T50/T59 Epson® Artisan 837
Epson® Stylus T23/T24/TX105/TX115
Epson® Stylus T40W/TX600FW/TX550W/TX610
Epson® Stylus T30
Epson® Stylus T33
Epson® Stylus TX515FN
Epson® Stylus TX510FN
Epson® Stylus T1100/TX510FN
Epson® WorkForce 40/500/600/610/615 Epson® WorkForce NX510/515
Epson® Stylus SX600FW/SX510W
Epson® Stylus ME OFFICE 80W/700FW
Epson® PX-201/502A/601F/602F

**RST-EPSON-3**  
(Epson new 7-pin inkjet chips)




T1411/T1412/T1413/T1414
T1371/T1371
T1241/T1242/T1243/T1244
T1251/T1252/T1253/T1254
T1261/T1262/T1263/T1264
T1271/T1272/T1273/T1274
T1281/T1282/T1283/T1284
T1291/T1292/T1293/T1294
T1301/T1302/T1303/T1304
ICBK62/ICC62/ICM62/ICY62
ICBK61/ICC62/ICM62/ICY62
ICBK61/ICC65/ICM65/ICY65
ICBK67/ICBK67
T1401/T1402/T1403/T1404

T1411/T1412/T1413/T1414
T1371/T1371
T1241/T1242/T1243/T1244
T1251/T1252/T1253/T1254
T1261/T1262/T1263/T1264
T1271/T1272/T1273/T1274
T1281/T1282/T1283/T1284
T1291/T1292/T1293/T1294
T1301/T1302/T1303/T1304
ICBK62/ICC62/ICM62/ICY62
ICBK61/ICC62/ICM62/ICY62
ICBK61/ICC65/ICM65/ICY65
ICBK67/ICBK67
T1401/T1402/T1403/T1404

Epson® ME 33/320/35/350 Epson® ME Office 620F/560W/960FWD/900WD/85ND (AP)
Epson® K200 (AP)
Epson® Stylus NX125/NX420 Epson® Workforce 323/325 (NA)
Epson® Stylus NX125/NX420 Epson® Workforce 323/325 (NA)
Epson® Workforce 630/60 Epson® Stylus NX430 (NA)
Epson® Workforce 630/60 (NA)
Epson® Stylus SX125/SX445W (EUR)
Epson® Stylus SX420W/SX525/SX525WD/SX620FW/SX445W/SX425W Epson® Stylus Office BX305F/BX305FW/BX625FWD/B42WD/BX925FWD (EUR)
Epson® Stylus SX525/SX620FW Epson® Stylus Office B42WD (EUR)
Epson® PX-430A/PX-403A/PX-404A/PX-434A/PX-675F (JP)
Epson® PX-503A/603F/203/ PX-675F (JP)
Epson® PX-673F/1600F/1200/1700F (JP)
Epson® PX-K100 (JP)
Epson Stylus Office TX620FWD (AUS)

**RST-EPSON-4**









T1801/T1802/T1803/T1804
T1811/T1812/T1813/T1814
T2001/T2002/T2003/T2004
T200XL1/T200XL2/T200XL3/T200XL4
T1701/T1702/T1703/T1704
T1711/T1712/T1713/T1714
T1621/T1622/T1623/T1624
T1631/T1632/T1633/T1634
ICBK69/ICC69/ICM69/ICY69
ICBK69L/ICC69/ICM69/ICY69
T2601/T2611/T2612/T2613/T2614
T2621/T2631/T2632/T2633/T2634
T2421/T2422/T2423/T2424/T2425/T2426
T2431/T2432/T2433/T2434/T2435/T2436
T2771/T2772/T2773/T2774/T2775/T2776
T277XL1/T277XL2/T277XL3/T277XL4/T277XL5/T277XL6
T2730/T2731/T2732/T2733/T2734

T1801/T1802/T1803/T1804
T1811/T1812/T1813/T1814
T2001/T2002/T2003/T2004
T200XL1/T200XL2/T200XL3/T200XL4
T1701/T1702/T1703/T1704
T1711/T1712/T1713/T1714
T1621/T1622/T1623/T1624
T1631/T1632/T1633/T1634
ICBK69/ICC69/ICM69/ICY69
ICBK69L/ICC69/ICM69/ICY69
T2601/T2611/T2612/T2613/T2614
T2621/T2631/T2632/T2633/T2634
T2421/T2422/T2423/T2424/T2425/T2426
T2431/T2432/T2433/T2434/T2435/T2436
T2771/T2772/T2773/T2774/T2775/T2776
T277XL1/T277XL2/T277XL3/T277XL4/T277XL5/T277XL6
T2730/T2731/T2732/T2733/T2734


Epson® Expression Home XP-30/XP-102/XP-202/XP-205/XP-302/XP-305/XP-402/XP-405 (EUR)
Epson® Expression Home XP-200/XP-300/XP-400 Epson® WorkForce WF-2520/WF-2530/WF-2540 (NA) (South America can not be reset)
Epson® Expression Home XP-103/XP-203/XP-207 (RU)
Epson® Workforce WF-2010W (EUR)
Epson® PX-535F/PX-045A/PX-046A/PX-405A/PX-435A (JP)
Epson® Expression Premium XP-600/XP-605/XP-700/XP-800 (EUR)
Epson® Expression Photo XP-850 (EUR)
Epson® Expression Premium XP-850 (NA)
Epson® Expression Premium XP-800 (NA)



			T273XL0/T273XL1/T273XL2/T273XL3/T273XL4	T273XL0/T273XL1/T273XL2/T273XL3/T273XL4	Epson® Expression Premium XP-600 (NA)
			T2551/T2561/T2562/T2563/T2564	T2551/T2561/T2562/T2563/T2564	Epson® Expression Premium XP-701 (CHN)
			ICBK70/ICC70/ICM70/ICY70/ICLC70/ICLM70	ICBK70/ICC70/ICM70/ICY70/ICLC70/ICLM70	
			ICBK70L/ICC70L/ICM70L/ICY70L/ICLC70L/ICLM70L	ICBK70L/ICC70L/ICM70L/ICY70L/ICLC70L/ICLM70L	Epson® EP-905F/EP-775AW (JP)
<b>RST-EPSON-6</b> Some starter cartridges have reset risk 		Epson VI	T2991/T2992/T2993/T2994	29BKXL/29CXL/29MXL/29YXL	Epson Expression Home XP-235/ XP-245/ XP-247/ XP-332/XP-335/XP-342/XP-345/XP-432/XP-435/XP-442/XP-445(EUR)
			T2981/T2982/T2983/T2984	29BK/29C /29M/29Y	
			T3351/T3361 /T3362/T3363/T3364	33BKXL/33PBKXL/33CXL/33MXL/33YXL	Epson Expression Premium XP-530/ XP-630/XP-830/XP-635/XP-540/XP-640/XP-645(EUR)
			T3331/T3341/T3342/T3343/T3344	33BK/33PBK/33C/33M /33Y	
			T3031/T3021/T3022/T3023/T3024	RDH-BK/RDH-BKL/RDH-C/RDH-M/RDH-Y	Epson PX-048A/049A
			T3101/T3102/T3103/T3104/T3105/T3106	YTH-BK/YTH-C/YTH-M/YTH-Y/YTH-R/YTH-GY	Epson EP-10VA/30VA
<b>RST-EPSON-7</b> 		Epson	AJE-KUIBK/KUIC/KUIM/KUIY/KUILC/KUILM	KUIBK/KUIC/KUIM/KUIY/KUILC/KUILM	Epson EP-879AW/AB/AR (JPN) <b>NEW !</b>
			AJE-KUIBK/L/KUICL/KUIML/KUIYL/KUILCL/KUILML	KUIBK/L/KUICL/KUIML/KUIYL/KUILCL/KUILML	
			34 BK/34 C/34 M/34 Y	34BK/34C/34M/34Y	Epson WorkForce Pro WF-3725DWF/3720DWF (EUR) <b>NEW !</b>
			34XL BK/34XL C/34XL M/34XL Y	34XLBK/34XLC/34XLM/34XLY	
			35 BK/35 C/35 M/35 Y	35BK/35C/35M/35Y	Epson WorkForce Pro WF-4740DTWF/4730DTW/4720DW/4725DW (EUR) <b>NEW !</b>
			35XL BK/35XL C/35XL M/35XL Y	35XLBK/35XLC/35XLM/35XLY	
			ICBK83 BK/ICC83 C/ICM83 M/ICY83 Y	ICBK83 BK/ICC83 C/ICM83 M/ICY83/Y	Epson PX-M780F/PX-M781F(JPN) <b>NEW !</b>
ICBK84 BK/ICC84 C/ICM84 M/ICY84 Y	ICBK84 BK/ICC84 C/ICM84 M/ICY84 Y				
<b>Z1</b> 		Canon	ARC-PGI5BK	PGI-5BK	Canon® PIXMA IP3300/IP4200/IP4300/IP4500 Canon® PIXMA IX4000/IX5000 Canon® PIXMA MP970
			ARC-CLI8BK	CLI-8BK	
			ARC-CLI8C	CLI-8C	Canon® PIXMA IP4200/IP4500/IP4300/IP5300 Canon® PIXMA Pro9000
			ARC-CLI8M	CLI-8M	
			ARC-CLI8Y	CLI-8Y	
			ARC-CLI8PC	CLI-8PC	
			ARC-CLI8PM	CLI-8PM	Canon® PIXMA Pro9000
			ARC-CLI8R	CLI-8R	
			ARC-CLI8G	CLI-8G	
			ARC-BCI9BK	BCI-9PGBK	Canon® PIXUS IP3300/IP4200/IP4300 Canon® PIXUS MP950/MP960/MP970
			ARC-BCI7BK	BCI-7eBK	
			ARC-BCI7C	BCI-7eC	Canon® PIXUS MP950/MP960/MP970/MP900 Canon® PIXUS PRO9000 Canon® PIXUS ip8600/ip9910
			ARC-BCI7M	BCI-7eM	
			ARC-BCI7Y	BCI-7eY	
			ARC-BCI7PC	BCI-7ePC	
			ARC-BCI7PM	BCI-7ePM	
			ARC-BCI7R	BCI-7eR	Canon® PIXUS ip8100/ip8600/ip9910 Canon® PIXUS Pro9000
			ARC-BCI7G	BCI-7eG	Canon® PIXUS ip8600/ip9910 Canon® PIXUS Pro9000
			ARC-PGI9R	PGI-9R	
			ARC-PGI9MBK	PGI-9MBK	
ARC-PGI9G	PGI-9G				
ARC-PGI9PM	PGI-9PM				


ARC-PGI9PC	PGI-9PC	Canon® PIXMA Pro9500	
ARC-PGI9Y	PGI-9Y		
ARC-PGI9C	PGI-9C		
ARC-PGI9GY	PGI-9GY		
ARC-PGI9PBK	PGI-9PBK		
ARC-PGI9M	PGI-9M		
ARC-BCI19BK	BCI-19BK		Canon® PIXUS ip100
ARC-BCI19C	BCI-19COLOR		Canon® PIXUS Mini260 Canon® PIXUS ip100
ARC-PGI35	PGI-35		Canon® PIXUS ip100
ARC-CLI36C	CLI-36C		Canon® PIXUS Mini260 Canon® PIXUS ip100
ARC-PGI1BK	PGI-1BK		Canon® PIXUS iX7000/MX7600
ARC-PGI2PBK	PGI-2PBK		Canon® PIXUS iX7000/MX7600 Canon® PIXUS Pro9500/Pro9500 Mark II
ARC-PGI2C	PGI-2C		
ARC-PGI2M	PGI-2M		Canon® PIXUS Pro9500/Pro9500 Mark II
ARC-PGI2Y	PGI-2Y		
ARC-PGI2GY	PGI-2GY		
ARC-PGI2G	PGI-2G		
ARC-PGI2R	PGI-2R		
ARC-PGI2PC	PGI-2PC		
ARC-PGI2PM	PGI-2PM		
ARC-PGI2MBK	PGI-2MBK		
CLI221BK	CLI-221BK	Canon® PIXMA (USA) iP3600/Ip4600 Canon® PIXMA (USA) MP540/MP620/MP630/MP980 Canon® PIXMA (USA) MX860/MX870	
CLI221C	CLI-221C		
CLI221M	CLI-221M		
CLI221Y	CLI-221Y		
PGI220BK	PGI-220BK	Canon® PIXMA MP980 (USA)	
CLI221GY	CLI-221GY		
BCI321BK	BCI-321BK	Canon® PIXUS iP3600/IP4600 Canon® PIXUS MP540/MP620/MP630/MP980/MX860/MX870 (JP)	
BCI321C	BCI-321C		
BCI321M	BCI-321M		
BCI321Y	BCI-321Y		
BCI320PGBK	BCI-320PGBK	Canon® PIXUS MP980 (JP)	
BCI321GY	BCI-321GY		
CLI521BK	CLI-521BK	Canon® PIXMA iP3600/iP4600 Canon® PIXMA MP540/MP620/MP630/MP980 Canon® PIXMA MX860/MX870 (EUR)	
CLI521C	CLI-521C		
CLI521M	CLI-521M		
CLI521Y	CLI-521Y		
PGI520BK	PGI-520BK	Canon® PIXMA MP980 (EUR)	
CLI521GY	CLI-521GY		
CLI821BK	CLI-821BK	Canon® PIXMA iP3680/iP4680 Canon® PIXMA MP545/MP628/MP988 Canon® PIXMA MX638/MX868/MX876 (CHN)	
CLI821C	CLI-821C		
CLI821M	CLI-821M		
CLI821Y	CLI-821Y		
PGI820BK	PGI-820BK	Canon® PIXMA MP988	
CLI821GY	CLI-821GY		
PGI-150PGBK-XL	PGI-150PGBK XL	Canon PIXMA IP7210/7110 Canon PIXMA MG5410 Canon PIXMA MX921 Canon PIXMA MX721 (LA)	
CLI-151BK-XL	CLI-151BK XL		
CLI-151C-XL	CLI-151C XL		
CLI-151M-XL	CLI-151M XL		
CLI-151Y-XL	CLI-151Y XL		
CLI-151GY-XL	CLI-151GY XL	Canon PIXMA MG6310(Six-color printer ,only GY can be applied to this model) (LA)	
PGI-250PGBK	PGI-250PGBK	Canon PIXMA IP7220/8720 Canon PIXMA MG5420 Canon PIXMA MX922/MX722 Canon Pixma MG6320/MG7120 Canon PIXMA IX6820 Canon MG5520 CanonMG6420 Canon MG6620 (NA)	
CLI-251BK	CLI-251BK		
CLI-251C	CLI-251C		
CLI-251M	CLI-251M		
CLI-251Y	CLI-251Y		

**RST-  
CANON-II**  
(Canon®II inkjet  
chips)



Canon

**RST-  
CANON-IV**  
(Canon®IV inkjet  
chips)




Canon

CLI-251GY	CLI-251GY	Canon PIXMA MG6320 /MG7520 (Six-color printer ,only GY can be applied to this model) (NA)
PGI-250PGBK-XL	PGI-250PGBK XL	Canon PIXMA IP7220/8720
CLI-251BK-XL	CLI-251BK XL	Canon PIXMA MG5420
CLI-251C-XL	CLI-251C XL	Canon PIXMA MX922/MX722
CLI-251M-XL	CLI-251M XL	Canon Pixma MG6320/MG7120
CLI-251Y-XL	CLI-251Y XL	Canon PIXMA IX6820 (NA) Canon MG5520 Canon MG6420 Canon MG6620
CLI-251GY-XL	CLI-251GY XL	Canon PIXMA MG6320 /MG7520 (Six-color printer ,only GY can be applied to this model) (NA)
PGI-255PGBK-XXL	PGI-255PGBK XXL	Canon PIXMA MX922 (NA)
BCI-350PGBK-XL	BCI-350PGBK XL	
BCI-351BK-XL	BCI-351BK XL	Canon PIXUS ip7230/ip8730
BCI-351C-XL	BCI-351C XL	Canon PIXUS MG5430
BCI-351M-XL	BCI-351M XL	Canon PIXMA MX923
BCI-351Y-XL	BCI-351Y XL	Canon PIXMA MX723
		Canon MG5530 / IX6830 (JPN)
BCI-351GY-XL	BCI-351GY XL	Canon PIXUS MG7530F/ MG7530/ MG7130/ MG6730/MG6530/MG6330/IP8730(Six-color printer ,only GY can be applied to this model) (JPN)
BCI-355PGBK-XXL	BCI-355PGBK XXL	Canon PIXMA MX723/MX923 (JPN)
PGI-450PGBK	PGI-450PGBK	
CLI-451BK	CLI-451BK	Canon PIXMA ip7240
CLI-451C	CLI-451C	Canon PIXMA MG5440
CLI-451M	CLI-451M	Canon PIXMA MX724
CLI-451Y	CLI-451Y	Canon PIXMA MX924 (MEA)
CLI-451GY	CLI-451GY	Canon PIXMA MG6340/MG7140(Six-color printer ,only GY can be applied to this model) (MEA)
PGI-450PGBK-XL	PGI-450PGBK XL	
CLI-451BK-XL	CLI-451BK XL	Canon PIXMA ip7240
CLI-451C-XL	CLI-451C XL	Canon PIXMA MG5440
CLI-451M-XL	CLI-451M XL	Canon PIXMA MX724
CLI-451Y-XL	CLI-451Y XL	Canon PIXMA MX924 (MEA)
CLI-451GY-XL	CLI-451GY XL	Canon PIXMA MG6340/MG7140(Six-color printer ,only GY can be applied to this model) (MEA)
PGI-550PGBK	PGI-550PGBK	
CLI-551BK	CLI-551BK	Canon PIXMA ip7250
CLI-551C	CLI-551C	Canon PIXMA MG5450
CLI-551M	CLI-551M	Canon PIXMA MX725
CLI-551Y	CLI-551Y	Canon PIXMA MX925
		Canon MG6450 /MG5550 /MG5650/IX6850 (EUR)
CLI-551GY	CLI-551GY	Canon PIXMA MG6350/MG7150 (Six-color printer ,only GY can be applied to this model) (EUR)
PGI-550PGBK-XL	PGI-550PGBK XL	
CLI-551BK-XL	CLI-551BK XL	Canon PIXMA ip7250
CLI-551C-XL	CLI-551C XL	Canon PIXMA MG5450
CLI-551M-XL	CLI-551M XL	Canon PIXMA MX725
CLI-551Y-XL	CLI-551Y XL	Canon PIXMA MX925
		Canon MG6450 / MG5550 / MG5650 /IX6850 (EUR)
CLI-551GY-XL	CLI-551GY XL	Canon PIXMA MG6350/MG7150 (Six-color printer ,only GY can be applied to this model) (EUR)
PGI-555PGBK-XXL	PGI-555PGBK XXL	Canon PIXMA MX725/MX925 (EUR)
PGI-650PGBK-XL	PGI-650PGBK XL	
CLI-651BK-XL	CLI-651BK XL	Canon PIXMA iP7260
CLI-651C-XL	CLI-651C XL	Canon PIXMA MG5460
CLI-651M-XL	CLI-651M XL	Canon PIXMA MX726
CLI-651Y-XL	CLI-651Y XL	Canon PIXMA MX926
		Canon IX6860 /IP8760 / MG5560 (AUS)
CLI-651GY-XL	CLI-651GY XL	Canon PIXMA MG6360(Six-color printer ,only GY can be applied to this model) (AUS)
PGI-750PGBK-XL	PGI-750PGBK XL	
CLI-751BK-XL	CLI-751BK XL	Canon PIXMA ip7270
CLI-751C-XL	CLI-751C XL	Canon PIXMA MG5470
CLI-751M-XL	CLI-751M XL	Canon PIXMA MX727
		Canon PIXMA MX927
		Canon MG6470 / MG5570 /IX6770 / MG6670 (AP)

**RST-  
CANON-VI**  
(Canon@VI inkjet  
chips)


CLI-751Y-XL	CLI-751Y XL	Canon MG7570 / IX6870
CLI-751GY-XL	CLI-751GY XL	Canon PIXMA MG6370(Six-color printer ,only GY can be applied to this model) (AP)
PGI-755PGBK-XXL	PGI-755PGBK XXL	Canon PIXMA MX727/MX927 (AP)
PGI-850PGBK-XL	PGI-850PGBK XL	
CLI-851BK-XL	CLI-851BK XL	Canon PIXMA ip7280
CLI-851C-XL	CLI-851C XL	Canon PIXMA MG5480
CLI-851M-XL	CLI-851M XL	Canon PIXMA MX728
CLI-851Y-XL	CLI-851Y XL	Canon PIXMA MX928
		Canon IX6880/MG5680 (CHN)
CLI-851GY-XL	CLI-851GY XL	Canon PIXMA MG6380/MG7180/ MG7580(Six-color printer ,only GY can be applied to this model) (CHN)
PGI-170PGBK	PGI-170PGBK	
CLI-171BK	CLI-171BK	
CLI-171C	CLI-171C	
CLI-171M	CLI-171M	
CLI-171Y	CLI-171Y	
CLI-171GY	CLI-171GY	Canon PIXMA MG7710 (Six colors including GY)
PGI-170PGBKXL	PGI-170PGBKXL	Canon PIXMA MG6810 (five colors)
CLI-171BKXL	CLI-171BKXL	Canon PIXMA MG5710 (five colors) (LA)
CLI-171CXL	CLI-171CXL	
CLI-171MXL	CLI-171MXL	
CLI-171YXL	CLI-171YXL	
CLI-171GYXL	CLI-171GYXL	
PGI-270PGBK	PGI-270PGBK	
CLI-271BK	CLI-271BK	
CLI-271C	CLI-271C	
CLI-271M	CLI-271M	
CLI-271Y	CLI-271Y	Canon PIXMA MG5720 (five colors)
CLI-271GY	CLI-271GY	Canon PIXMA MG5721 (five colors)
		Canon PIXMA MG5722 (five colors)
PGI-270PGBKXL	PGI-270PGBKXL	Canon PIXMA MG6820 (five colors)
CLI-271BKXL	CLI-271BKXL	Canon PIXMA MG6821 (five colors)
CLI-271CXL	CLI-271CXL	Canon PIXMA MG6822 (five colors)
CLI-271MXL	CLI-271MXL	Canon PIXMA MG7720 (Six colors including GY) (NA)
CLI-271YXL	CLI-271YXL	
CLI-271GYXL	CLI-271GYXL	
BCI-370PGBK	BCI-370PGBK	
BCI-371BK	BCI-371BK	
BCI-371C	BCI-371C	
BCI-371M	BCI-371M	
BCI-371Y	BCI-371Y	
BCI-371GY	BCI-371GY	Canon PIXMA MG7730 (Six colors including GY)
		Canon PIXMA MG6930 (Six colors including GY)
BCI-370PGBKXL	BCI-370PGBKXL	Canon PIXMA MG5730 (five colors) (JPN)
BCI-371BKXL	BCI-371BKXL	Canon PIXUS TS9030/TS8030(Six colors including GY)
BCI-371CXL	BCI-371CXL	Canon PIXUS TS6030/TS5030 (five colors)



Canon

BCI-371MXL	BCI-371MXL	
BCI-371YXL	BCI-371YXL	
BCI-371GYXL	BCI-371GYXL	
PGI-470PGBK	PGI-470PGBK	
CLI-471BK	CLI-471BK	
CLI-471C	CLI-471C	
CLI-471M	CLI-471M	
CLI-471Y	CLI-471Y	
CLI-471GY	CLI-471GY	Canon PIXMA MG7740 (Six colors including GY) Canon PIXMA MG6840 (five colors) Canon PIXMA MG5740 (five colors) (MEA)
PGI-470PGBKXL	PGI-470PGBKXL	
CLI-471BKXL	CLI-471BKXL	
CLI-471CXL	CLI-471CXL	
CLI-471MXL	CLI-471MXL	
CLI-471YXL	CLI-471YXL	
CLI-471GYXL	CLI-471GYXL	
PGI-570PGBK	PGI-570PGBK	
CLI-571BK	CLI-571BK	
CLI-571C	CLI-571C	
CLI-571M	CLI-571M	Canon PIXMA MG5750 (five colors) Canon PIXMA MG5751 (five colors) Canon PIXMA MG5752 (five colors) Canon PIXMA MG5753 (five colors) Canon PIXMA MG6850 (five colors) Canon PIXMA MG6851 (five colors) Canon PIXMA MG6852 (five colors) Canon PIXMA MG6853 (five colors)
CLI-571Y	CLI-571Y	
CLI-571GY	CLI-571GY	Canon PIXMA MG7750 (Six colors including GY) Canon PIXMA MG7751 (Six colors including GY) Canon PIXMA MG7752 (Six colors including GY) Canon PIXMA MG7753 (Six colors including GY) (EUR)
PGI-570PGBKXL	PGI-570PGBKXL	
CLI-571BKXL	CLI-571BKXL	
CLI-571CXL	CLI-571CXL	
CLI-571MXL	CLI-571MXL	
CLI-571YXL	CLI-571YXL	
CLI-571GYXL	CLI-571GYXL	
PGI-670PGBK	PGI-670PGBK	
CLI-671BK	CLI-671BK	
CLI-671C	CLI-671C	
CLI-671M	CLI-671M	
CLI-671Y	CLI-671Y	Canon PIXMA MG7760 (Six colors including GY) Canon PIXMA MG7765 (Six colors including GY) Canon PIXMA MG7766 (Six colors including GY) Canon PIXMA MG6860 (five colors) Canon PIXMA MG5760 (five colors) Canon PIXMA MG6865 (five colors) Canon PIXMA MG5765 (five colors) (AUS)
CLI-671GY	CLI-671GY	
PGI-670PGBKXL	PGI-670PGBKXL	
CLI-671BKXL	CLI-671BKXL	
CLI-671CXL	CLI-671CXL	
CLI-671MXL	CLI-671MXL	
CLI-671YXL	CLI-671YXL	
CLI-671GYXL	CLI-671GYXL	

		PGI-770PGBK	PGI-770PGBK	Canon PIXMA MG77700 (Six colors including GY) Canon PIXMA MG6870 (five colors) Canon PIXMA MG5770 (five colors) (AP)	
		CLI-771BK	CLI-771BK		
		CLI-771C	CLI-771C		
		CLI-771M	CLI-771M		
		CLI-771Y	CLI-771Y		
		CLI-771GY	CLI-771GY		
		PGI-770PGBKXL	PGI-770PGBKXL		
		CLI-771BKXL	CLI-771BKXL		
		CLI-771CXL	CLI-771CXL		
		CLI-771MXL	CLI-771MXL		
		CLI-771YXL	CLI-771YXL		
		CLI-771GYXL	CLI-771GYXL		
		PGI-870PGBK	PGI-870PGBK		Canon PIXMA MG7780 (Six colors including GY) Canon PIXMA MG6880 (five colors) Canon PIXMA MG5780 (five colors) (CHN)
		CLI-871BK	CLI-871BK		
		CLI-871C	CLI-871C		
CLI-871M	CLI-871M				
CLI-871Y	CLI-871Y				
CLI-871GY	CLI-871GY				
PGI-870PGBKXL	PGI-870PGBKXL				
CLI-871BKXL	CLI-871BKXL				
CLI-871CXL	CLI-871CXL				
CLI-871MXL	CLI-871MXL				
CLI-871YXL	CLI-871YXL				
CLI-871GYXL	CLI-871GYXL				
PGI-970PGBK	PGI-970PGBK	Canon PIXMA MG77900 (Six colors including GY) Canon PIXMA MG5795 (five colors) Canon PIXMA MG5790 (five colors) (KOR)			
CLI-971BK	CLI-971BK				
CLI-971C	CLI-971C				
CLI-971M	CLI-971M				
CLI-971Y	CLI-971Y				
CLI-971GY	CLI-971GY				
PGI-970PGBKXL	PGI-970PGBKXL				
CLI-971BKXL	CLI-971BKXL				
CLI-971CXL	CLI-971CXL				
CLI-971MXL	CLI-971MXL				
CLI-971YXL	CLI-971YXL				
CLI-971GYXL	CLI-971GYXL				
RST- BROTHER R-1 (non-started cartridge)			LC110BK	LC110BK	Brother® DCP-J152N
			LC110C	LC110C	
			LC110M	LC110M	
		LC110Y	LC110Y		
		LC111BK	LC111BK	Brother® DCP-J952N	
		LC111C	LC111C	Brother® MFC-J870N	
LC111M	LC111M	Brother® DCP-J752N			
				Brother® MFC-J880DN	



LC111Y	Brother® MFC-J980DWN
LC113BK	
LC113C	Brother® MFC-J4510N Brother® DCP-L4210N
LC113M	
LC113Y	



Brother

After reset, Unismart device only displays the "Reset OK" or "Reset Fail"

LC117BK	Brother® DCP-J4520N (JP)
LC115C	
LC115M	
LC115Y	
LC123BK	Brother® MFC-J 4610 DW
LC123C	Brother® MFC-J 4410 DW
LC123M	Brother® MFC-J 4510 DW
LC123Y	(EUR)
LC127BK	Brother® MFC-J 4610 DW
LC125C	Brother® MFC-J 4410 DW
LC125M	Brother® MFC-J 4510 DW
LC125Y	(EUR)
LC129BK	Brother® MFC-J6920 DW
LC101BK	Brother® MFC-J 870 DW
LC101C	Brother® MFC-J 875 DW
LC101M	Brother® MFC-J 450 DW
LC101Y	Brother® MFC-J 650 DW
LC103BK	
LC103C	
LC103M	
LC103Y	Brother® MFC-J4510DW
LC107BK	Brother® MFC-J4410DW
LC105C	Brother® MFC-J4610DW
LC105M	(NA)
LC105Y	
LC109BK	Brother® MFC-J6920 DW
LC-563BK	
LC-563C	Brother® MFC-J2510
LC-563M	(AP)
LC-563Y	
LC-567XL-BK	
LC-565XL-C	Brother® MFC-J2510
LC-565XL-M	(AP)
LC-565XL-Y	
LC133BK	
LC133C	
LC133M	
LC133Y	Brother® MFC-J4510N
LC137BK	(AUS)
LC135C	
LC135M	
LC135Y	
LC161BK	
LC161C	Brother® DCP-J152W
LC161M	Brother® DCP-J752 DW
LC161Y	Brother® MFC-J245
LC163BK	Brother® MFC-J470 DW
LC163C	Brother® MFC-J650 DW
LC163M	Brother® MFC-J870 DW
LC163Y	
LC121BK	DCP-J132W DCP-J152W
LC121C	DCP-J552W DCP-J752W
LC121M	DCP-J172W MFC-J870DW
LC121Y	MFC-J650DW MFC-J470DW
LC131BK	
LC131C	DCP-J132W /DCP-J152W/DCP-J552W/ DCP-J752W /DCP-J172W/MFC-J870DW/MFC-
LC131M	J650DW/MFC-J470DW



**RST-  
BROTHER-2**  
(Original)

**RST-  
BROTHER-2-  
N**  
(Non-Original)




Brother

After reset, Unismart device only displays the "Reset OK" or "Reset Fail"

**BR3**  
(Original data)


LC131Y		
LC209XXLBK	Brother MFCJ5520DW / J5620DW / J5720DW	(US)
LC207XXLBK	Brother MFCJ4320DW / J4420DW / J4620DW	(US)
LC205XXLC		
LC205XXLM	Brother MFCJ4320DW / J4420DW / J4620DW	(USA)
LC205XXLY	Brother MFCJ5520DW / J5620DW / J5720DW	
LC203BK	Brother MFC-J460DW/ MFC-J480DW/ MFC-J485DW/ MFC-J680DW/ MFC-J880DW/ MFC-J885DW	
LC203C	(Above printers can only use LC203/LC201)	
LC203M		
LC203Y		
LC229XXLBK	Brother MFC-J5320DW / J5620DW / J5625DW / J5720DW	(EUR)
LC223BK	Brother DCP-4120DW	
LC223C	Brother MFC-J4420DW / J4620DW / J4625DW	(EUR)
LC223M	Brother MFC-J5320DW / J5620DW / J5625DW / J5720DW	
LC223Y	Brother DCP-J562DW/MFC-J480DW/MFC-J680DW/MFC-J880DW	(Above printers can only use LC223/LC221)
LC217XXLBK	Brother DCP-J4220N-B/W	
LC215XLC	Brother MFC-J4720N	(JPN)
LC215XLM		
LC215XLY	Brother DCP-J4220N-B/W 4225N-W/B	
LC213BK	Brother MFC-J4720N /J4725N	
LC213C	Brother MFC-J5620CDW / J5720CDW / J5820DW	(JPN)
LC213M		
LC213Y		
LC669XXLBK		
LC665XLC		
LC665XLM		
LC665XLY	Brother MFC-J2320	
LC663BK	Brother MFC-J2720	(HK)
LC663C		
LC663M		
LC663Y		
LC3029BK	LC3029BK	
LC3029C	LC3029C	Brother MFC-J5830DW/J5830DW XL/J6535DW/ J6535DW XL/J5930DW/J6935DW (US)
LC3029M	LC3029M	
LC3029Y	LC3029Y	
LC3017BK	LC3017BK	
LC3017C	LC3017C	
LC3017M	LC3017M	
LC3017Y	LC3017Y	Brother MFC-J5330DW/J6530DW/J6930DW/ J6730DW (US)
LC3019BK	LC3019BK	
LC3019C	LC3019C	
LC3019M	LC3019M	
LC3019Y	LC3019Y	
LC3217BK	LC3217BK	
LC3217C	LC3217C	
LC3217M	LC3217M	
LC3217Y	LC3217Y	Brother MFC- J5330DW/J5335DW/J5730DW/J5930DW/J6530DW/J6930DW/J6935DW (EUR)
LC3219BK	LC3219BK	
LC3219C	LC3219C	
LC3219M	LC3219M	
LC3219Y	LC3219Y	
LC3317BK	LC3317BK	
LC3317C	LC3317C	
LC3317M	LC3317M	



Brother

LC3317Y	LC3317Y	Brother MFC-J5330DW/J5730DW/J6530DW/J6930DW/J6730DW (AU)
LC3319BK	LC3319BK	
LC3319C	LC3319C	
LC3319M	LC3319M	
LC3319Y	LC3319Y	
LC3329BK	LC3329BK	Brother MFC-J5930DW/J6935DW (AU)
LC3329C	LC3329C	
LC3329M	LC3329M	
LC3329Y	LC3329Y	
LC3129BK	LC3129BK	
LC3129C	LC3129C	
LC3129M	LC3129M	
LC3129Y	LC3129Y	
LC3117BK	LC3117BK	Brother MFC-J6980CDW/J6580CDW (JPN)
LC3117C	LC3117C	
LC3117M	LC3117M	
LC3117Y	LC3117Y	
LC3119BK	LC3119BK	
LC3119C	LC3119C	
LC3119M	LC3119M	
LC3119Y	LC3119Y	
LC3617BK	LC3617BK	
LC3617C	LC3617C	
LC3617M	LC3617M	
LC3617Y	LC3617Y	
LC3619BK	LC3619BK	
LC3619C	LC3619C	
LC3619M	LC3619M	
LC3619Y	LC3619Y	
LC3719BK	LC3719BK	Brother MFC-J2330DW Brother MFC-J3930DW (ME) NEW!
LC3719C	LC3719C	
LC3719M	LC3719M	
LC3719Y	LC3719Y	
LC3213BK	LC3213BK	Brother MFC-J890DW/J895DW Brother DCP-J772DW/J774DW (EUR) NEW!
LC3213C	LC3213C	
LC3213M	LC3213M	
LC3213Y	LC3213Y	
LC3029BK-N	LC3029BK	Brother MFC-J5830DW/J5830DW XL/J6535DW/ J6535DW XL/J5930DW/J6935DW (US)
LC3029C-N	LC3029C	
LC3029M-N	LC3029M	
LC3029Y-N	LC3029Y	
LC3017BK-N	LC3017BK	Brother MFC-J5330DW/J6530DW/J6930DW/ J6730DW (US)
LC3017C-N	LC3017C	
LC3017M-N	LC3017M	
LC3017Y-N	LC3017Y	
LC3019BK-N	LC3019BK	
LC3019C-N	LC3019C	
LC3019M-N	LC3019M	
LC3019Y-N	LC3019Y	
LC3217BK-N	LC3217BK	
LC3217C-N	LC3217C	
LC3217M-N	LC3217M	
LC3217Y-N	LC3217Y	
LC3219BK-N	LC3219BK	
LC3219C-N	LC3219C	

**BR3**  
(Original data)



Brother

LC3219M-N	LC3219M
LC3219Y-N	LC3219Y
LC3317BK-N	LC3317BK
LC3317C-N	LC3317C
LC3317M-N	LC3317M
LC3317Y-N	LC3317Y
LC3319BK-N	LC3319BK
LC3319C-N	LC3319C
LC3319M-N	LC3319M
LC3319Y-N	LC3319Y
LC3329BK-N	LC3329BK
LC3329C-N	LC3329C
LC3329M-N	LC3329M
LC3329Y-N	LC3329Y
LC3129BK-N	LC3129BK
LC3129C-N	LC3129C
LC3129M-N	LC3129M
LC3129Y-N	LC3129Y
LC3117BK-N	LC3117BK
LC3117C-N	LC3117C
LC3117M-N	LC3117M
LC3117Y-N	LC3117Y
LC3119BK-N	LC3119BK
LC3119C-N	LC3119C
LC3119M-N	LC3119M
LC3119Y-N	LC3119Y
LC3617BK-N	LC3617BK
LC3617C-N	LC3617C
LC3617M-N	LC3617M
LC3617Y-N	LC3617Y
LC3619BK-N	LC3619BK
LC3619C-N	LC3619C
LC3619M-N	LC3619M
LC3619Y-N	LC3619Y
LC3719BK-N	LC3719BK
LC3719C-N	LC3719C
LC3719M-N	LC3719M
LC3719Y-N	LC3719Y
LC3213BK-N	LC3213BK
LC3213C-N	LC3213C
LC3213M-N	LC3213M
LC3213Y-N	LC3213Y

Brother MFC-J5330DW/J5730DW/J6530DW/J6930DW/J6730DW (AU)

Brother MFC-J5930DW/J6935DW (AU)

Brother MFC-J6995CDW (JPN)

Brother MFC-J6980CDW/J6580CDW (JPN)

Brother MFC-J2330DW/J2730DW/J3530DW/3930DW (AP)

Brother MFC-J2330DW  
Brother MFC-J3930DW (ME) NEW!

Brother MFC-J890DW/J895DW  
Brother DCP-J772DW/J774DW (EUR) NEW!

**BR3**  
(Starter cartridge  
Non-Original  
data)







Brother

LC3029BK-S	LC3029BK
LC3029C-S	LC3029C
LC3029M-S	LC3029M
LC3029Y-S	LC3029Y
LC3017BK-S	LC3017BK
LC3017C-S	LC3017C
LC3017M-S	LC3017M
LC3017Y-S	LC3017Y
LC3217BK-S	LC3217BK
LC3217C-S	LC3217C
LC3217M-S	LC3217M
LC3217Y-S	LC3217Y
LC3219BK-S	LC3219BK

Brother MFC-J5830DW/J5830DW XL/J6535DW/  
J6535DW XL/J5930DW/J6935DW (US)

Brother MFC-J5330DW/J6530DW/J6930DW/  
J6730DW (US)

Brother MFC-  
J5330DW/J5335DW/J5730DW/J5930DW/J6530DW/J6930DW/J6935DW (EUR)

		<table border="1"> <tr><td>LC3219C-S</td><td>LC3219C</td></tr> <tr><td>LC3219M-S</td><td>LC3219M</td></tr> <tr><td>LC3219Y-S</td><td>LC3219Y</td></tr> <tr><td>LC3129BK-S</td><td>LC3129BK</td></tr> <tr><td>LC3129C-S</td><td>LC3129C</td></tr> <tr><td>LC3129M-S</td><td>LC3129M</td></tr> <tr><td>LC3129Y-S</td><td>LC3129Y</td></tr> <tr><td>LC3117BK-S</td><td>LC3117BK</td></tr> <tr><td>LC3117C-S</td><td>LC3117C</td></tr> <tr><td>LC3117M-S</td><td>LC3117M</td></tr> <tr><td>LC3117Y-S</td><td>LC3117Y</td></tr> </table>	LC3219C-S	LC3219C	LC3219M-S	LC3219M	LC3219Y-S	LC3219Y	LC3129BK-S	LC3129BK	LC3129C-S	LC3129C	LC3129M-S	LC3129M	LC3129Y-S	LC3129Y	LC3117BK-S	LC3117BK	LC3117C-S	LC3117C	LC3117M-S	LC3117M	LC3117Y-S	LC3117Y	<p>Brother MFC-J6995CDW (JPN)</p> <p>Brother MFC-J6980CDW/J6580CDW (JPN)</p>																										
LC3219C-S	LC3219C																																																		
LC3219M-S	LC3219M																																																		
LC3219Y-S	LC3219Y																																																		
LC3129BK-S	LC3129BK																																																		
LC3129C-S	LC3129C																																																		
LC3129M-S	LC3129M																																																		
LC3129Y-S	LC3129Y																																																		
LC3117BK-S	LC3117BK																																																		
LC3117C-S	LC3117C																																																		
LC3117M-S	LC3117M																																																		
LC3117Y-S	LC3117Y																																																		
<p><b>BR3</b> (Starter cartridge Non-Original data)</p> 		<p>Brother</p> <table border="1"> <tr><td>LC3029BK-N-S</td><td>LC3029BK</td></tr> <tr><td>LC3029C-N-S</td><td>LC3029C</td></tr> <tr><td>LC3029M-N-S</td><td>LC3029M</td></tr> <tr><td>LC3029Y-N-S</td><td>LC3029Y</td></tr> <tr><td>LC3017BK-N-S</td><td>LC3017BK</td></tr> <tr><td>LC3017C-N-S</td><td>LC3017C</td></tr> <tr><td>LC3017M-N-S</td><td>LC3017M</td></tr> <tr><td>LC3017Y-N-S</td><td>LC3017Y</td></tr> <tr><td>LC3217BK-N-S</td><td>LC3217BK</td></tr> <tr><td>LC3217C-N-S</td><td>LC3217C</td></tr> <tr><td>LC3217M-N-S</td><td>LC3217M</td></tr> <tr><td>LC3217Y-N-S</td><td>LC3217Y</td></tr> <tr><td>LC3219BK-N-S</td><td>LC3219BK</td></tr> <tr><td>LC3219C-N-S</td><td>LC3219C</td></tr> <tr><td>LC3219M-N-S</td><td>LC3219M</td></tr> <tr><td>LC3219Y-N-S</td><td>LC3219Y</td></tr> <tr><td>LC3129BK-N-S</td><td>LC3129BK</td></tr> <tr><td>LC3129C-N-S</td><td>LC3129C</td></tr> <tr><td>LC3129M-N-S</td><td>LC3129M</td></tr> <tr><td>LC3129Y-N-S</td><td>LC3129Y</td></tr> <tr><td>LC3117BK-N-S</td><td>LC3117BK</td></tr> <tr><td>LC3117C-N-S</td><td>LC3117C</td></tr> <tr><td>LC3117M-N-S</td><td>LC3117M</td></tr> <tr><td>LC3117Y-N-S</td><td>LC3117Y</td></tr> </table>	LC3029BK-N-S	LC3029BK	LC3029C-N-S	LC3029C	LC3029M-N-S	LC3029M	LC3029Y-N-S	LC3029Y	LC3017BK-N-S	LC3017BK	LC3017C-N-S	LC3017C	LC3017M-N-S	LC3017M	LC3017Y-N-S	LC3017Y	LC3217BK-N-S	LC3217BK	LC3217C-N-S	LC3217C	LC3217M-N-S	LC3217M	LC3217Y-N-S	LC3217Y	LC3219BK-N-S	LC3219BK	LC3219C-N-S	LC3219C	LC3219M-N-S	LC3219M	LC3219Y-N-S	LC3219Y	LC3129BK-N-S	LC3129BK	LC3129C-N-S	LC3129C	LC3129M-N-S	LC3129M	LC3129Y-N-S	LC3129Y	LC3117BK-N-S	LC3117BK	LC3117C-N-S	LC3117C	LC3117M-N-S	LC3117M	LC3117Y-N-S	LC3117Y	<p>Brother MFC-J5830DW/J5830DW XL/J6535DW/J6535DW XL/J5930DW/J6935DW (US)</p> <p>Brother MFC-J5330DW/J6530DW/J6930DW/J6730DW (US)</p> <p>Brother MFC-J5330DW/J5335DW/J5730DW/J5930DW/J6530DW/J6930DW/J6935DW (EUR)</p> <p>Brother MFC-J6995CDW (JPN)</p> <p>Brother MFC-J6980CDW/J6580CDW (JPN)</p>
LC3029BK-N-S	LC3029BK																																																		
LC3029C-N-S	LC3029C																																																		
LC3029M-N-S	LC3029M																																																		
LC3029Y-N-S	LC3029Y																																																		
LC3017BK-N-S	LC3017BK																																																		
LC3017C-N-S	LC3017C																																																		
LC3017M-N-S	LC3017M																																																		
LC3017Y-N-S	LC3017Y																																																		
LC3217BK-N-S	LC3217BK																																																		
LC3217C-N-S	LC3217C																																																		
LC3217M-N-S	LC3217M																																																		
LC3217Y-N-S	LC3217Y																																																		
LC3219BK-N-S	LC3219BK																																																		
LC3219C-N-S	LC3219C																																																		
LC3219M-N-S	LC3219M																																																		
LC3219Y-N-S	LC3219Y																																																		
LC3129BK-N-S	LC3129BK																																																		
LC3129C-N-S	LC3129C																																																		
LC3129M-N-S	LC3129M																																																		
LC3129Y-N-S	LC3129Y																																																		
LC3117BK-N-S	LC3117BK																																																		
LC3117C-N-S	LC3117C																																																		
LC3117M-N-S	LC3117M																																																		
LC3117Y-N-S	LC3117Y																																																		

**Note:**

The chip pictures shown above may not always match the exactly pictures of OEM's.

The Jig with "standard" means it is standard configuration for the first-time buyer. "optional" means it costs extra.

The red words mean the new models updated by this version.

All reset OEM chips of Epson cannot be used in the printers with strictly encryption in South America.